



**CR-CP-FB**

# **INSTALLATION MANUAL**





<https://www.thecrowgroup.com/>

# Table of Contents

Architecture .....	3
Features and Capabilities .....	3
Overview & Communication Capabilities.....	5
Installing .....	7
Web Installer Access .....	9
Quick Install Guide.....	10
Voice Device .....	13
User Types ,Code, Pendants,Tag.....	18
User Settings.....	18
User Options .....	18
User Type .....	19
Area Assignment .....	19
Keypad Assignment.....	19
Permissions.....	20
Pendants .....	20
Access Tag .....	21
Areas .....	22
Area Names .....	22
Settings .....	22
Timers and Delays.....	22
Zone Assignment .....	23
User Assignment .....	23
Time Zone Assignment.....	24
Signals to Output .....	24
Area account numbers .....	24
Beeps to Keypads .....	24
Zones .....	25
Zone Status.....	25
Area Assignment .....	26
Working Mode .....	26
Zones Options .....	27
Camera Assignment .....	28
Zone Key switch.....	28
Alarm to Output .....	29
Delays and timers .....	30
Radio Zones .....	31
<b>Zone Configuration –features &amp; options examples:</b> .....	31
Re-trigger .....	33
Output Type .....	35

Time Zone Assignment .....	36
Timing .....	37
Add Output .....	37
Alarm to Output .....	38
Chime Alarm Reset By .....	39
Report Channels .....	40
Channel Type .....	40
Settings .....	41
Area account numbers .....	42
Reporting Options .....	42
Keypads .....	44
Radio Keypads .....	44
SH-KP Icon Keypad Overview .....	44
Settings .....	45
Area Assignment .....	46
Communication .....	47
Remote Access .....	47
Communication Options .....	47
TCP/IP .....	48
GSM .....	48
Wi-Fi .....	49
DECT .....	50
RF .....	51
Miscellaneous .....	54
Chime Control .....	54
User Options .....	54
Miscellaneous .....	55
Panel Options .....	55
Voice device (DECT Device) .....	58
Overview .....	59
Control .....	60
Log .....	60
...More .....	60
Disconnect .....	60
CrowCloud™ Web Services .....	60
Mobile Applications .....	66
Appendix 1: Installer Event log messages .....	67

## Box content

	<b>1 x CR-CP-FB</b>
	<b>1 x AC Adapter</b> <i>(already plugged)</i>
	<b>1 x RJ45 Ethernet Cable</b> <i>(already plugged)</i>
	<b>1 x Battery backup</b>

## Architecture

### Features and Capabilities

<b>Users</b>	Up to 64 Users Codes, and/or pendants, and/or Tags
<b>Zones</b>	Up to 128 Zones in Total, ISM (RF), Extender ISM(RF)or/and DECT zones Working modes options (normal, 24H, Chime, Zone is a key switch...) Remotely zone configuration Zone supervision
<b>Outputs</b>	Up to 64 in Total, ISM (RF) ,ISM Extender or/and DECT outputs
<b>Partitions (areas)</b>	Up to 4 With Area Name customization
<b>Alarm Detection devices</b>	PIR, CRT, EDS3000AM, Magnet Contact, Glass break detector, Smoke detector, MAG&Shock, AQ, and many more...see CROW web site for more devices types
<b>Visual verification</b>	Up to 16 indoor or outdoor PIRCAM or mix of both detectors in total
<b>Audio verification</b>	SH-AVM is an indoor audio verification module, originating emergency end to end user phone calls
<b>Home Comfort devices</b>	Using DECT or Zigbee ACP Smart Plug
<b>Safety Devices</b>	Smoke , Flood ,Temperature and Humidity detectors
<b>Signaling Devices</b>	Indoor and Outdoor sirens


<b>Communication</b>	GSM/GPRS/4G support VoLTE Ethernet WI-FI SMS messages and SMS Control Commands GSM calls for SH-AVM module full duplex calls
<b>GSM modem</b>	Model :L610-EU (FIBOCOM) LTE Cat1 LTE Bands supported: B1/B3/B7/B8/B20/B28 Fall Back: 2G (900/1800MHz)
<b>USB-C connector</b>	For Factory use Only
<b>Up To 8 report channels</b>	TCP/IP channel Wi-Fi channel GSM/GPRS /4G channel Backup function between communication report channels SMS Full Duplex voice calls on panic event or originating calls (with DECT Voice devices)
<b>Multi-protocol support to CMS</b>	CROW - (CROW receiver server SW installation required on the CMS side) SIA DC09 – SIA DCS SIA-09 (ADM-CID) SIA Null – event time control programmable reporting options
<b>Log Events</b>	+2000 events
<b>Time Zones</b>	Up to 32 Time zones for Area - Arm/Disarm Time zone for an output Time zone for user
<b>Cloud and Mobile Services</b>	Admin Management, Web installer page, End User Mobile App on Android and iOS
<b>Remote Programming</b>	Via Web browser interface
<b>Communication Protocol</b>	Freewave2™ Two Way ISM GFSK with 5 frequencies & LBT DECT ULE
<b>Advanced RF module</b>	based on Chip EFR32FG23
<b>Frequency Bands (MHz)</b>	868MHz or 916MHz
<b>Operating Range</b>	Up to 800 meters open space
<b>Installer and User Codes</b>	1 Installer code 20 End Users Each user code is 4 digits, number of variations 10000 (different users can't have the same code)
<b>Arming Modes</b>	Total, Stay, Latchkey, Duress, Bypass

## SPECIFICATIONS

SPECIFICATIONS		
<b>ELECTRICAL</b>	Power Input	230VAC 0.4A, 50Hz
	Power Supply Type	External AC/DC Adaptor 5.6V / 1.6A
	Low Battery Threshold	3.6V ( $\pm 0.1V$ ) DC
	Low Battery restore Threshold	3.9V ( $\pm 0.1V$ ) DC
	Backup Battery Type	Battery Pack 3.7V/5500mAh
	Time to Charge	Less than 24 hours
	Battery Autonomy	1 single battery More than 12 Hours (w/o DECT active)
	Battery Charge Max current	Approx. 500mA
	Current Consumption	Average: 120mA (with DECT active 230mA)
<b>PHYSICAL PROPERTIES</b>	Dimensions	175 x 1758 x 28 mm
	Weight	0.9 Kg with battery
	Operating Temperature Range	0 ° C to 40 ° C
	Operating Humidity Range	0 to 95%
	Storage Temperature Range	-20 ° C to 60 ° C


## Overview & Communication Capabilities

### Panel View



1	LED Indicators
2	Screw opening
3	RJ45 Ethernet connector (connect to router)
4	Power AC Connector
5	Battery connector
6	SIM Card slot for Micro SIM Card
7	Tamper Switch for bracket removal protection

## Bracket View



## Led Indications

SYSTEM STATUS	LED INDICATION		
	Panel status	Power	Communication
System is armed	RED	-	-
System is in Arm process	RED Blink	-	-
Burglary Alarm	RED Blink		
Panic Alarm	Led state no change	-	
System is disarmed and Ready to Arm	Green	-	-
System is disarmed and NOT Ready to Arm	LED Off	-	-
Main power and Back up Battery are OK	-	Green Blink	-
Battery missing OR Battery in charge mode	-	Green / RED Blink	-
AC fail – system working on back up battery Mode	-	RED Blink	-
System working with main communication method (Ethernet)	-	-	Green Blink
System working with backup communication method (WIFI or GSM)	-	-	Green / RED Blink
No communication method	-	-	LED Off
Remote configuration connection	-	-	Green
WPS mode	Green Blink	Green Blink	Green Blink

## Installing

**Note:** CR-CP-FB must be installed close to a power socket and connected to an Internet connection through Ethernet RJ45 cable, Wi-Fi or GPRS/4G.

If you wish to use GSM/GPRS/4G feature, please install a micro SIM card (not supplied) into your panel and make sure that the quality of reception is sufficient.




Unscrew the holding screw

---



Tilt Out the panel cover

---




Place the unit on the wall and use the water level indicator to position it straight.

Mark the holding holes on the wall and drill the wall.

Mount the unit on the wall with screws

---




Ethernet –  
Connect the cable  
to a router or an  
internet outlet

GSM – Insert  
micro-SIM card  
into the SIM card  
slot


AC – Plug into a  
power outlet

---



Connect the  
backup battery

---



Insert back the  
front cover by  
tilting it inside

Close the holding  
screw

Connect the AC  
adapter to  
electricity

# Configuring the panel

## Overview

**Note!** : Find all Parameters Definitions in **Program Definitions description** chapter in this manual

## Web Installer Access

Web installer Access link: <https://installer.crowcloud.com> – Installer should use this link to login into system and to be able to manage, program and control the system.

Ensure that you have an installer account prior any installation (if not, please ask for it from your Distributor).

After mounting the control panel, connect it to the AC power and to the internet via the Ethernet cable plugged into the router. Verify communication led is flashing in green color. Panel uses its MAC Address to communicate to the Crowcloud™, so any search or connect based on panel's MAC Address or name.

**Important Note:** Do not use the same account details for Installer and for End user account, accounts must be different.

The installer must verify with his distributor whether he has been assigned to a subgroup of panels or the distributor has a registration code to use the option of take ownership of certain panels he has purchased from the distributor


Installer opens account with registration code option: <https://installer.crowcloud.com> and uses the “Sign up” button to open new installer account with registration code (installer must obtain the registration code from his distributor)

The panel by default automatically connect and register on the CrowCloud™.

The configuration of the panel has to be performed through the web installer interface.

This part of the CrowCloud™ allows access to an online full configuration interface of the control panel.

The below screenshot shows an example of web page screen:



## Quick Install Guide

Enter the installer code (by default the code is 000000).



For security reasons, it is highly recommended to change the installer code. Go to "Miscellaneous", change the installer code in Panel Options, and submit.

### Users codes and names

---

CR-CP-FB panel can manage up to 64 users. Click on User level to change its code and name

Learn remote pendant by inserting its unique ID number and submit configuration.



**Note:** to activate pendants, press and hold the two lower buttons of the remote control device.

Remote led shows green light on the end of learning successfully.

### Areas Names

---

The panel offers up to 4 areas (partitions), select the Area # to program and see all options.

### Zones

---

CR-CP-FB offers up to 120 wireless zones (60 ISM and 60 DECT ULE devices), click on required zone # to display its options.

#### Learning ISM devices

Select the required zone # to display its options, Add Zone, Insert Link Type:" ISM", Insert unique ID number of the device, Select Device Type. Set up working mode of the zone (Stay mode, 24-hour...) Specify Area activation assignment and etc, insert battery/batteries to complete the learn of device, Save Configuration.

#### Learning DECT devices

The pairing of DECT ULE device must be preliminarily performed from "Communication" → "DECT" → "Learn DECT Device". Press the device's pairing button until the device's LED starts flashing. When the DECT device pairing is done successfully, you can then go to "Radio Zones" and assign the DECT device ID to a zone.

Click Save Configuration to save changes and activate learned zones.

## Outputs

---

CR-CP-FB panel offers up to 64 wireless outputs (ISM and/or DECT ULE and/or Zigbee e.g. AC Smart Plugs)

### Learning ISM devices

Select the required Output # to display its options, Add Output, Insert Link Type:" ISM", Insert unique ID number of the device, Select Device Type. Set up the configuration, Save Configuration.

### Learning DECT devices

The pairing of DECT ULE device must be preliminarily performed from "Communication" → "DECT" → "Learn DECT Device".

When the DECT device pairing is done, then you can go to "Outputs" and assign the DECT ID to an output.

### Learning Zigbee devices

The pairing of Zigbee device must be preliminarily performed from "Communication" → "ZIGBEE" → "Learn ZIGBEE Device".

When the ZIGBEE device pairing is done, then you can go to "Outputs" and assign the ZIGBEE ID to an output.

## Report Channels

---

CUBE+™ panel offers 8 report channels. Channel #8 is dedicated channel for cloud (cannot be modified), select 1-7 report channel # to display its options.

Set the channel according: 1. Channel Type 2. Settings 3. Protocol type 4. Port no. 5. Area account code 6. Report options.

### Select channel type as follow:

<b>TCP / IP</b>	Set channel type as TCP/IP Need to set Ethernet enabled to use this type of channel
<b>Wi-Fi</b>	Set channel type as Wi-Fi. Need to set Wi-Fi enabled to use this type of channel
<b>GSM IP</b>	Set channel type as GPRS 4G. Need to set 4G IP enabled to use this type of channel in setting "Communication" → "GSM" (see below in para "Communication")
<b>GSM (SMS +Voice)</b>	Set channel type as SMS Text Messages (Note: GSM Voice for panic event + AVM module only )
<b>VOICE</b>	Set channel type as VOICE (when using a Voice Box module for event announcements )

NOTE: The TCP/IP, GSM IP and GSM SMS channels are enabled by default.

## Keypads

---

Up to 4 Keypads per system, select Keypad # and start to program by Add Keypad button, select Link type "ISM", insert Keypad ID # (serial number), and select Device type, save configuration.

- Find installation and learning instructions for each device stored in the CROW website section support and download.

## Communication

---

Default remote access password is "12345678", it is recommended to modify the password.

Activate communication paths configured in "Report Channels".

### TCP/IP:

By default, the DHCP is active; the router will assign an internal IP to the panel. You can assign a dedicated IP address to the panel by filling its static IP, Subnet mask and its Gateway (address of the router).

### GSM IP:

This option activates the GPRS/4G. Fill in the APN of your provider.

### GSM SMS:

This option activates SMS features if selected in "Report Channels".

### Wi-Fi:

The panel can connect to the router in Wi-Fi mode.

Fill in the network SSID (name of the wireless network), Security type and network password.

### DECT:

Pairing of DECT devices in communication->DECT level and go to "Zones" or "Outputs" to assign paired devices.

### RF Repeater:

The panel can support up to 4 wireless repeaters. Insert the ID number of the repeater.

### RF

In case of jamming, you can adjust manually the RF Channel frequency range from 1 to 5.

## Miscellaneous

---

There are panel options such as:

Installer code

Duress digit

License time

Timers and Delays

User Options

Chime Control


- **Find descriptions of above options and program parameters in Program Definitions Description chapter in this manual.**

Audio Verification Module

SH-AVM is an indoor audio verification module. Upon transmission of an alarm signal, the SH-AVM provides remotely controlled and full duplex functionality between a central station operator and the occupants of the premises. Receiving audio verification simultaneously with the alarm signal allows the CMS to prioritize and verify alarms before acting, making the SH-AVM the ideal solution to false dispatching and unverified alarm problems. Up to 5 modules can easily be installed in any convenient location in your home.

NOTE: make sure your system is equipped with working GSM SIM card.


VOICE DEVICE




The SH-AVM is a DECT module; therefore, AVM module must be paired first in communication level->Learn DECT device,

How to pair the voice device module:


1. Ensure to charge the AVM battery first (USB charger)
2. Go to communication level → Go to DECT sub level, press on the learn DECT device button, and press the pairing button of the voice device located in the back side of the voice device and the dial green led in the front should be flashing while the system is running the learning process. Verify in the web installer screen that shows stage 1 and stage 2 finished and completed and successfully learned message.
3. Next step, assign the pairing voice device to selected voice device # ( 1 to 5) by Add Voice device button.
4. Go to Voice device level and add the new voice device



5. Insert from 1 to 16 Outgoing Destination numbers for Panic call event in Communication -> Alarm Phone.



6. Insert Phone destination number to make a call by pressing the dial button, USER-> select user #-> phone.( see below picture.)



7. Save configuration

## DOOR BELL


### Audio Security Burglar Preventing Device

Crow's SH-DB is a smart wireless doorbell burglar-preventing device with two-way audio-DECT. Audio is routed over GSM from the device to the smartphone for audio verification. Smart recorded messages enable to trigger a discussion while the panel calls the user who is not at home or not willing or able to answer. When used with Crow's cameras, day and night high definition images will be sent for video verification. When someone arrives at an outside door, they press a button that alerts one or multiple inside voice devices and then the people inside the house can talk to them by pressing a button on the Voice Device's dial button.

NOTE: The Door Bell learned as a Voice device  
For learning process please proceed to Device's instruction

### Doorbell – Voice device Interaction Architecture

6



## Call Scenarios:

1. **System in DISARM mode:** pressing the doorbell button, voice Device ringing (locally call).
2. **System in ARM mode:** pressing the doorbell button, panel generates GSM call to any predefined destination number
3. Pressing voice device's Panic button, panel generates GSM call to any predefined destination number
4. Pressing the Voice device's Dial button, panel generates GSM call to any predefined destination number
5. Call Disconnect Button
6. End user can Call the control panel and the call can be answered in the Voice device by pressing the dial button ( no.4)

**Reminder Note:** Do not forget to insert SIM card to support voice calls

## Overview

---

This level displays general information such as device state, device type, RSSI, battery level, Zones, Users, Outputs information. Battery and RSSI level statistics per hour, day, week and more.

Diagnostic sub level shows the relevant and current panel communication type is online. Information on Ethernet, GSM, panel Radio Frequency, Wi-Fi details.

In Addition, there is a walk test tool, which helps installer to test the system, verify all works properly before leaving the site.

- Battery Status
- Ethernet network status with internal connection status.
- Wi-Fi connection status
- GSM and GPRS / 4G status with RSSI level
- ISM 2-Way Wireless Radio information (Perform Walk Test)

## Walk Test


---

Click on "Start Walk Test" to start the test. Check Zones connection status, device type and RSSI signal of each ISM detectors.

By cross walking through all the detectors connected to the system and activating them, the associated zone will latch up to allow verification that all zones are communicating properly with control panel.

The results of the walk-test displayed on the screen to verify which detectors triggered during walk-test mode.

The screenshot below describes triggering detector while the system is in walk test mode:



#ID	Name	Serial	State	Type	RSSI	R	Check	Active
9	Zone 9	2805367	Open	Magnet & Vibration sensor		No	✓	●

Press "Exit & Stop Walk Test" button, the walk-test mode will be terminated.

Note: the communication panel led shows orange color while the system is in walk test mode.

## Control

---

This is a level for installer testing the system that allows the system be ARM, DISARM or STAY ARM for each AREA.

## More...

---

More level displays information such as Panel MAC address, Status, version, Panel's IP address, last connection, Time Zone, country, there is ability of:

Backup configuration

Panel upgrade (from cloud or local file)

Creating default file configuration (installer can create his own default configuration)

Apply default configuration

Link to personal page

Restart panel

## End User Personal Web Page

---



After installation is done, End user should run the next link <http://Crowcloud.com> and proceed with the user registration to your panel.


The Crow Cloud personal user webpage allows the end user direct access to all of his own registered control panels and:

- Monitor and Control panel and connected devices
- Browse alarm pictures and request for immediate take picture
- Get panel connection info
- Manage cloud users
- And more...

If you already have an account, insert your account details and log in, or create a new user account by clicking "Sign Up"

### Creating End User Account steps:

1. Press the [Sign-up](#) button
2. Fill in End user account details (use relevant email address)
3. The password must be alphanumeric and have at least 8 characters



4. Submit
5. Run the link [www.crowcloud.com](http://www.crowcloud.com) again
6. Login with new account details
7. Press on the Add panel to Account button and associate the new account with the end user panel's MAC Address.
8. Remote access password must be modify from default , please ask your installer to modify it first
9. The user code is by default 1234, recommended to change it.
10. Press on the next button

## Add panel to account

MAC address

Panel Name

Remote access password

User code

[Next](#)

## Mobile Applications

### Smartphone iOS and Android

Install the Crow Pro application on your smartphone (iOS / Android)



Whether you are at home, at work, on a business trip, or on vacation, The Crow Pro™ application provides you the easiest way to monitor and control your system:

- Switch between linked panels (home, office...)
- Control panel state (Arm, Disarm...)
- Check latest events
- See and Operate on active Outputs (Activate/Deactivate)
- See and Operate Zones (Activate/Deactivate Bypass)
- Take picture from connected Pircam(s)
- View stored pictures and Share them (via mail, message...)
- Access to Panel & Users Info

### **Preliminary Important Note:**

Configuration changes will take effect only when you send the updated configuration to the control panel.

We highly recommend saving your latest configuration before each update.

## Program Definitions description

User Types ,Code, Pendants,Tag

Click on the user to display its available options.

User Settings

Parameter	Description	Default Configuration
<b>User Name</b>	Enter name of user up to 16 characters	User #
<b>User Code</b>	Enter user code (4-8 digits)	Code 1 defaults to 1234. This means that User 1 automatically gets the code 1234
<b>Phone</b>	Enter user's Phone number ( creating full duplex call by pressing the call button of Voice Device)	Empty

User Options

Parameter	Description	Default Configuration
<b>User code can arm</b>	User can arm all areas that assigned to user	Enable
<b>User code can arm stay</b>	User can arm Stay Mode for all areas that assigned to user	Disable
<b>User code can disarm</b>	User can disarm all areas that assigned to user	Enable
<b>User code can disarm stay</b>	User can disarm Stay Mode for all areas that assigned to user	Enable
<b>Security Guard User</b>	User can arm all areas that assigned to user, but may only disarm if the panel is currently armed and in the alarm state	Disable
<b>Latchkey Mode User</b>	The User will arm the alarm in Latchkey Mode. If a user with this option on disarms the alarm no disarm report will be sent via the dialer. If Latchkey Mode is armed and a user with this option off disarms the alarm a disarm report will be sent to alert parents when their children have returned home. Reporting of Latchkey Disarm is enabled at Reporting Options.	Disable
<b>Code required after access tag</b>	After presenting access tag user has to enter a valid user code	Disable
<b>User Emergency Alarm</b>	When this option is checked / activated, the panic event is replaced by an emergency event and also the CID to the monitoring station alarm is different	CID 101

### User Type

Parameter	Description	Default Configuration
<b>Keypad User</b>	Users assigned to keypads; User Codes used to Arm/Disarm all or part of the alarm system.	Disable
<b>Pendant User</b>	Radio keys can be used to Arm/Disarm all or part of the alarm or they can operate outputs directly', Unlike user codes, a radio key cannot be assigned to a keypad so if a radio key is assigned to more than one output and the radio key is operated, all of the outputs assigned to the radio key will turn on	Disable
<b>Access Tag User</b>	Access Tag can be used to Arm/Disarm all or part of the alarm or it can be used to operate outputs for access control purposes	Disable
<b>Remote Control User</b>	This option defines user rights for remote control of the control panel.	Disable User 1 is enable by default

### Area Assignment

Parameter	Description	Default Configuration
<b>User Assigned To Area</b>	Codes uses to Arm/Disarm all or part of the alarm system or they use to operate outputs for access control purposes.	All users assigned to Area 1

### Keypad Assignment

Parameter	Description	Default Configuration
<b>User can operate at keypad</b>	Any user assigned to operate at certain Keypads. This option controls a code that can Arm/Disarm from certain keypads.	

## Time Zone Assignment

Parameter	Description	Default Configuration
<b>User Controlled by Time Zone</b>	When the user controlled by time zone, the keypad code and pendant are not active, when the time zone is not started or finished. Only when the time zone started, the user can perform actions in the system in accordance with its rights as defined by configuration.	Not assigned

## Handset Assignment

Parameter	Description	Default Configuration
<b>User assignment to handset</b>	The device refers to the SH-fall device, this feature used to associate handset to a user, the system supports up to 4 devices, and each of the devices is associated with one user only. When activating an example panic from SH-Fall, the system creates an event that contains the user name ID.	Disable

## Permissions

Parameter	Description	Default Configuration
<b>User can change his code and name</b>	The user can change his code number and name	Enable for all users
<b>User can change all codes and names</b>	They user can change code number and name for all users.	Disabled

## Pendants

Parameter	Description	Default Configuration
<b>Learn user pendant</b>	Enter the unique serial ID of the pendant (remote control) or Panic watch device and save configuration	Empty
<b>Delete user pendant</b>	Delete existing pendant from memory Delete user pendant and send configuration to panel	-
<b>Pendant can disarm at alarm only</b>	If this option is enable, the pendant can disarm the alarm during alarm only. If this option is off, the pendant cannot disarm the panel in any state.	Disable
<b>Pendant can disarm at entry delay only</b>	If this option is on, the pendant can only disarm the alarm during the entry delay time. This means that authorized radio key users must enter the building and trigger the entry delay before the can disarm the alarm.	Disable

<b>On pendant panic alarm call voice</b>	A feature must enabled in the check box if we want a two-way voice call in the event of a panic, for instance, from a panic watch device. in order to establish a two-way voice call, we must ensure at least one voice device is set up in the system. So that the call will establish between the voice device and the destination end user's phone.	disable
<b>Pendant Panic , Fire, Medical Alarm to Outputs</b>	A Pendant Panic, Fire, Medical Alarm can be assigned to an Output or multiple Outputs. This can be used to operate an audible or visual alarm connected to the Output	No Outputs selected

#### Access Tag

<b>Parameter</b>	<b>Description</b>	<b>Default Configuration</b>
<b>Learn user tag</b>	The access Tag must enrolled into the panel before it can used, learn done by RFID point in the keypad, please ensure that this user already has a code otherwise, the RFID will not function normally.	
<b>Delete user tag</b>	Delete a tag done from web installer page by delete button.	
<b>Access tag can arm</b>	If this option is on, access tag can arm area assigned to user	Enable
<b>Access tag can disarm</b>	If this option is on, access tag can disarm area assigned to user	Enable
<b>Access tag can Turn On/Off Output</b>	Access Tag can be assign to an Output or multiple Outputs. This can be used to operate an audible or visual alarm connected to the Output	No Outputs selected

## Areas

Click on an Area to display its available options.

### Area Names

Parameter	Description	Default Configuration
Area Name	Enter name to identify the Area	Area #

### Settings

Parameter	Description	Default Configuration
Report Arm at the end of Exit Delay	If this option is on the panel will report the Arm/Stay Arm signal to a monitoring station when the exit delay expires. If it is off, the panel will report the arm signal immediately the system has been armed	Not Selected
Use near and verified alarm to report	To reduce the possibility of false alarms the panel can require two alarms on different zones within a 45 minutes period before a full alarm is sent. If this option is turned ON it applies to all zones assigned to that area. An alarm on a single zone will send a Near Alarm report to the monitoring station. If no further alarms occur within 45 minutes, the near alarm timer is reset and a restore is sent for the zone that activated. If the zone that activated is still in alarm when the 45 minutes timer expires, a zone bypass for that zone is sent and the zone will remain bypassed until the area is disarmed. Any new alarms after the timer has expired will send another Near Alarm report. If a second alarm on a different zone occurs within 45 minutes of the Near alarm, an Intrusion Verified alarm report will be sent. This format only applies to Contact ID and Pager reporting. Turning this option on will stop zone alarms from being reported in Domestic & Voice formats as there are no messages for near and confirmed alarms. You must turn this option off if using Domestic or Voice formats	Not Selected
Fail to arm if exit zone still open	If this option is turned ON it doesn't give to arm or stay arm the area if one of the low security zones or exit delay zones still open after exit delay expired. This option not valid for automatic arm by time zone.	Not Selected

### Timers and Delays

Parameter	Description	Default Configuration
Area Exit Delay Time (sec)	Each Area can have its own exit delay time. The delay can be programmed from 1-255 seconds in one second increments. If the exit delay is set to '0' the panel will be instantly armed.	60 seconds
Area exit stay delay time (sec)	Each Stay Mode Area can have their own exit delay time. The delay can be programmed from 1-255 seconds in one second increments. If the exit delay is set to '0' the panel will be instantly armed.	60 seconds

<p><b>Area delinquency delay time (days)</b></p>	<p>Each Area can have their own Delinquency time. The delinquency time monitors the arm/disarms of each Area. If an Area has not been armed within the set number of days a delinquency report will be sent.</p> <p>Each time an Area is armed the delinquency timer is reset. A value of '0' disables the delinquency monitoring.</p> <p><b>NOTE:</b> If the default value of '0' is changed at this location (e.g. a value of 10 is entered meaning 10 days), the next time the area is armed a delinquency restore message will be sent via the dialer as a test that the function is operating</p>	<p>0 second (immediate)</p>
<p><b>Area inactive time (Min.)</b></p>	<p>Each Area can have own inactive time. The inactive time monitors a lack of activity for each Area at disarm. If an Area has not been, activate within the set number of minutes an inactive zone report will be sent. Each time an Area is activated the inactive timer is reset. A value of '0' disables the inactive monitoring</p>	<p>0</p>
<p><b>Area alarm restore time (Min.)</b></p>	<p>The feature it is dedicated to auto reset for Panic, Fire and Medical alarms events, In case there is no KP installed in the system. This is the time (in minutes) that all those events will be restored, &lt;&lt;0&gt;&gt; means that user must use Manually to restore the alarm whether is with a code or pendant or from mobile App. &lt;&lt;X&gt;&gt; minutes means that the alarm will be restored after &lt;&lt;X&gt;&gt; minutes.</p>	<p>0</p>

#### Zone Assignment

Parameter	Description	Default Configuration
<p><b>Assigned Zones</b></p>	<p>This option assigns Zone(s) to Area.</p> <p>If a Zone is assigned only to one area it will activate if specified area is armed. If zone assigned to more than one area it will activate only when all assigned areas are armed. By default all zones assigned to Area 1.</p>	<p>All zones assigned to Area 1</p> <p>Areas 2, 3 and 4 not selected</p>

#### User Assignment

Parameter	Description	Default Configuration
<p><b>User Assignment</b></p>	<p>This option assigns Users to Areas.</p> <p>If Users have this option activated, they can Arm/Disarm all zones assigned to Area</p>	<p>All Users assigned to Area 1</p> <p>Areas 2, 3 and 4 not selected</p>

### Time Zone Assignment

Parameter	Description	Default Configuration
<b>Time Zones</b>	If area assigned to time-zone it will automatically armed when time-zone starts and disarmed when finished. You can assign more than one time-zone to each area. If assigning multiple time-zones you should insure that they do not overlap as this could cause confusion	

### Signals to Output

Parameter	Description	Default Configuration
<b>Arm Area Indication to Outputs</b>	For monitoring purposes, an Arm indication can be assigned to an Output. It could be used to start a video recorder or similar device. Each Area can have a separate arm indication assigned to a different output if required	No Outputs selected
<b>Stay Arm Area Indication to Outputs</b>	For monitoring purposes, a Stay Arm indication can be assigned to an Output. Each Area can have a separate indication assigned to a different output if required	No Outputs selected
<b>Disarm Area Indication to Outputs</b>	For monitoring purposes, a Disarm indication can be assigned to an Output. Each Area can have a separate disarm indication assigned to a different output if required	No Outputs selected

### Area account numbers

Parameter	Description	Default Configuration
<b>Area Account numbers</b>	When system sends a report to a monitoring station there must be a unique account number programmed in report channels from 1-7 to identify the panel. There is an account code for each area.  The account code is 4 digits. Each digit can be a number from 0-9 as well as the special characters B, C, D, E & F. For SMS report channels no need to define the account number.	All account in report channels from 1-7 are set "0" except the channel #8 with account "8000" for CrowCloud™ connection

### Beeps to Keypads

Parameter	Description	Default Configuration
<b>Area Armed Exit Delay Beeps to Keypad</b>	This option is using for monitoring purposes of exit delay at arming by keypad beeping. If the option marked for specified area corresponded keypad will start beeps during time of arm exit delay, but no longer than given by buzzer reset time.	Enable for all keypads
<b>Area Stay Armed Exit Delay Beeps to Keypad</b>	This option is using for monitoring purposes of exit delay at stay arming by keypad beeping. If the option marked for specified area corresponded keypad will start beeps during time of stay arm exit delay, but no longer than given by buzzer reset time.	Disable

## Zones

The Panel supports up to 128 Zones in Total, ISM (RF), Extender ISM(RF) or/and DECT zones

We invite you to visit our website <http://www.thecrowgroup.com> for more information on our Two-Way wireless ISM and DECT detectors range.

To configure Zones, click on the zone to display its related options.

Parameter	Description	Default Configuration
<b>Name</b>	Enter zone name	
<b>Add Zone</b>	This option used for enrolling new device RF, DECT or Extender and assign it to a zone and setting the device's configuration	

### Zone Status

Parameter	Description	Default Configuration
<b>Zone is active</b>	Activate or deactivate the zone, The panel will monitor the zone.	zone is activated automatically right after enrolling and learning a new device
<b>Stay mode zone</b>	Zone will cause alarm if triggered when Stay Mode is armed. This feature is normally used for arming just part of the alarm at night time.	All zones selected
<b>Is Two trigger zone</b>	If this option is ON the zone will have to trigger twice within the two trigger time before it will cause an alarm. If the zone does not trigger a second time before the two trigger time expires, the count is reset and it will take another two triggers to cause an alarm on this zone. If more than one zone is set-up as a two trigger zone, then a single trigger from two separate zones within the two trigger time can also cause an alarm. If the zone becomes faulty and still open once triggered at end of two trigger time period it will also cause an alarm.	No Zone selected
<b>Exit delay zone</b>	Zone should be closed for ready to arm. It will not cause an instant alarm if triggered during the exit delay time.	All zones selected
<b>Can Arm if Zone is not Ready</b>	Zone can remain open during arming and will cause alarm in case it will remain open after the exit delay expired. This zone is named "Low Security Zone".	No Zone selected
<b>Outdoor Zone</b>	A special feature for detectors that installed outside the premises, which mainly indicates to the control Monitoring center that the alert came from an external and not internal detector, such as the code according to the CMS. Zone will send Outdoor alarm (1136) in instead alarm (1130)	disable

<b>Handover zone</b>	A Handover Zone is one that its entry delay will apply provided a Non-Handover entry zone is triggered first. If no other entry delay zones are triggered before the handover zone the entry delay on that zone does not apply and the alarm will become instant (no entry delay)	No Zone selected
<b>Manually bypassed zone</b>	Zone can be manually bypassed while in the disarmed state. Once the area with the bypassed zone has been armed and then disarmed, the manual bypass is canceled and the zone must be manually bypassed again before arming if required.	All zones selected
<b>Auto bypassed zone</b>	Zone will be auto-bypassed if unsealed at the expiry of the exit delay. If a zone is unsealed at the time of arming and remains unsealed when the exit delay expires and this option is on for that zone it will be automatically bypassed by the panel. If the zone seals after that time it will be re-instated automatically and can then cause an alarm. On disarming of the alarm any auto-Bypasses are removed	No Zone selected
<b>Disable Zone Tamper</b>	If this option is turned ON then the zone tamper will be disabled, opening or removing the zone from the wall will not cause to tamper alarm on panel.	No Zone selected

#### Area Assignment

Parameter	Description	Default Configuration
<b>Zone assigned to Areas</b>	This option assigns the Zone to Area. If a Zone is assigned only to one area, it will activate if specified area is armed. If zone assigned to more than one area, it will activate only when all assigned areas are armed. By default all zones assigned to Area 1.	All Zones assigned to Area 1 only.

#### Working Mode

Parameter	Description	Default Configuration
<b>Normal</b>	Zone without any special behavior.	All zones selected
<b>24-hour zone</b>	If this option is ON the zone will be constantly monitored regardless of the arm/disarm state of the panel. If the 24 Hour zone also has an entry delay programmed, this delay will apply. Once the alarm has been generated it must be cleared by entry of a valid User code	No Zones selected
<b>24-hour auto-reset zone</b>	If this option is ON the zone will be constantly monitored regardless of the arm/disarm state of the panel. Once an alarm has been generated with a 24-Hour Auto-reset zone, the alarm will be reset automatically once the zone is closed. If the 24-Hour zone also has an entry delay programmed, this delay will apply. If the 24-Hour zone activates but then resets before the entry delay expires no alarm will be generated. This feature can be useful for monitoring plant type alarms such as freezer alarms.	No Zones selected

<b>24-hour fire zone</b>	If this option is ON the zone will be constantly monitored regardless of the arm/disarm state of the panel. If the 24-Hour Fire zone also has an entry delay programmed, this delay will apply. Once the alarm has been generated it must be cleared by entry of a valid User code.	No Zones selected
<b>24-hour Water zone</b>	If this option is ON the zone will be constantly monitored regardless of the arm/disarm state of the panel. If the 24-Hour Water zone also has an entry delay programmed, this delay will apply. Once the alarm has been generated it must be cleared by entry of a valid User code.	No Zones selected
<b>24-hour Gaz zone</b>	If this option is selected the zone will be constantly monitored regardless of the arm/disarm state of the panel. Once the alarm has generated, it must be cleared by entry of a valid User code.	
<b>24-hour High temperature zone</b>	If this option is selected the zone will be constantly monitored regardless of the arm/disarm state of the panel. Once the alarm has generated, it must be cleared by entry of a valid User code. This is a special feature that the HIGH temperature alarm event replaces the regular alarm (open/close) event from a detector	
<b>24-hour Low temperature zone</b>	If this option is selected the zone will be constantly monitored regardless of the arm/disarm state of the panel. Once the alarm has generated, it must be cleared by entry of a valid User code. This is a special feature that the LOW temperature alarm event replaces the regular alarm (open/close) event from a detector	
<b>Chime</b>	If this option is ON, the zone will operate Chime mode when disarmed. When the alarm is armed the Chime Mode is disabled for this zone. A Chime zone can sound the keypad buzzer or operate an output to indicate that the zone is unsealed. It is normally used to monitor areas during the daytime	No Zones selected
<b>Permanent chime</b>	If this option is ON, the zone will operate Chime mode when armed or disarmed. When the alarm is armed the zone will continue to only be a Chime Mode Zone and will not cause a burglar alarm. A Chime zone can sound the keypad buzzer or operate an output to indicate that the zone is unsealed	No Zones selected
<b>Zone is key switch</b>	This option enables zone as a keyswitch function	No Zones selected

#### Zones Options

Parameter	Description	Default Configuration
<b>Zone will not report alarm to channels 1-7</b>	This option disables the zone to send alarm report including camera photos through all enabled communication channels 1-7 In addition, there is no activation of siren and KP buzzer. special event code 4130 indication and "shadow event name assigned to this feature.	Disable (unchecked)

<b>Zone will not send alarm to channel 8</b>	This option disables the zone to send alarm report, excluding camera photos through channel 8,	Disable (unchecked)
<b>Zone Sends Reports</b>	This option enables the zone to send report function through all enabled communication channels.	All Zones Selected
<b>Zone is on Soak Test</b>	If a zone is suspected of being faulty and is causing false alarms, you can turn it into a Soak Test Zone and it will still be monitored for alarms when armed but it will not cause the sirens to sound or report to the dialer. The Soak Test zone will still be logged in the event memory however so it is possible to check the activity of the zone, via the memory, and after a suitable period of no alarms it can be re-instated as part of the alarm by removing the Soak Test option	No Zones selected
<b>Exit Terminator Zone</b>	If this option is selected, when the zone unseals during the exit delay time and then seals again the panel will cancel any remaining exit delay time and arm in 3 seconds from the time the zone was sealed.	No Zones selected
<b>Trigger if open</b>	The camera will be triggered in any panel state mode.	No Zones selected

#### Camera Assignment

Parameter	Description	Default Configuration
<b>Zone is assigned to Cameras</b>	This option enables the zone to trigger PIRCAM or multiple PIRCAMs.	No Zones selected

#### Zone Key switch

Parameter	Description	Default Configuration
<b>Key Switch can ARM</b>	This option enables Arming of the assigned Area via the Keyswitch	
<b>Key Switch can DISARM</b>	This option enables Disarming of the assigned Area via the Key-switch	
<b>Key Switch is normally open</b>	The key-switch can be a NO (Normally Open) or a NC (Normally Closed) key-switch.	

<p><b>Key Switch is momentary</b></p>	<p>The operation of the key-switch can be momentary or latching. If this option is on, the key-switch operation is assumed to be momentary. This means that each time the key-switch is operated then released the area will toggle its current state (I.e. if armed it will become disarmed or vice versa). If this option is turned off it is assumed that the key-switch is a latching type. This means that when the key-switch is operated and the key removed the contacts remain in the same state. When a latching key-switch is used, turning on the switch will arm the area and turning it off will disarm the area.</p>	
---------------------------------------	---	--

Alarm to Output

Parameter	Description	Default Configuration
<p><b>Zone alarm to outputs</b></p>	<p>If an Area is Armed and a zone assigned to that Area activates, the zone can trigger selected Outputs for local alarm signaling. This location assigns Zones to Outputs for alarms that occur when in the Full Armed State</p>	<p>No Outputs selected</p>
<p><b>Zone stay alarm to outputs</b></p>	<p>If an Area has Stay Mode Armed and a zone assigned to that Area activates, the zone can trigger selected Outputs for local alarm signaling. This location assigns Zones to Outputs for alarms that occur when Stay Mode is Armed</p>	<p>No Outputs selected</p>
<p><b>Zone 24H alarm to outputs</b></p>	<p>If a zone is programmed as one of 24 Hour type zone and if it is open then the selected output(s) is activated for local alarm signaling. In case of standard 24-hour zone the output will be active for the full reset time. In case of 24-hour auto-reset zone the output is deactivated when the reset time expires or if zone is closed. If a zone is a 24-hour fire zone then the output will pulse at a rate equals to the pulse time for that output.</p>	<p>No Outputs selected</p>
<p><b>Zone tamper to outputs</b></p>	<p>Zone tamper can trigger selected output(s) for local alarm signaling.</p>	<p>No Outputs selected</p>
<p><b>Chime zone alarm to outputs</b></p>	<p>If a zone is programmed as a Chime zone and it activates, the zone can trigger selected Outputs for local alarm signaling. The output will operate for the Chime to Output time at location. The zone must clear before the output can be activated again</p>	<p>No Outputs selected</p>

<b>Zone near alarm to outputs</b>	If zones are programmed for near and verified alarms, it is also possible to get an indication of a near alarm from any of the 16 outputs using this program location. A near alarm is the first alarm during an armed period	No Outputs selected
<b>Zone verified alarm to outputs</b>	If zones are programmed for near and verified alarms, it is also possible to get an indication of a verified alarm from any of the 16 outputs using this program location. A verified alarm is the second alarm from a different zone to the one that caused the near alarm and must happen within 45 minutes of the near alarm	No Outputs selected

Delays and timers


<b>Parameter</b>	<b>Description</b>	<b>Default Configuration</b>
<b>Armed zone entry delay time (seconds)</b>	Each Zone has it's own Entry Delay time when in the Full Armed State. The delay can be programmed from 0 to 9999 seconds in one-second increments. If the entry delay is set to 0 the zone will be an instant zone.	All zones are selected
<b>Stay mode entry delay time (seconds)</b>	Each Zone has it's own Entry Delay time when in Stay Mode. The delay can be programmed from 0 to 9999 seconds in one-second increments. If the entry delay is set to 0 the zone will be an instant zone.	All zones are selected
<b>Zone Sensor watch-time (minutes)</b>	If value of this option is greater than zero then zone will be checked to see that it operates during the disarmed state. If it is not operated within the specified time a 'Sensor-watch' alarm will be generated. This feature is designed to detect a faulty zone that is not operating normally or one that has had its detection area blocked. The timer is stopped when the area assigned to the zone is armed and resumes with the specified value when disarmed again. The timer is reset back to the original value every time the zone operates while disarmed. The range of values from 0 to 9999 minutes.	All zones are selected

## Radio Zones

Parameter	Description	Default Configuration
<b>Name</b>	Enter name to identify the Zone	Zone #
<b>Add Zone (Learn Radio zone)</b>	<p>Radio detector must be enrolled into the panel before it can be used.            Select zone # , Add Zone -&gt; Link Type :ISM or DECT , Device's ID, Device type</p> <p><b>Note:</b>            The pairing of DECT ULE device must be preliminarily performed from "Communication" → "DECT" → "Learn DECT Device".            When the DECT device pairing is done, then you can go to "Radio Zones" and assign the DECT device ID to a zone.</p>	
<b>Delete radio zone</b>	Removing radio zone from the system.	-
<b>Zone Config</b>	This function set remotely the radio zone parameters such as led on/off, pulse detection, Pet immunity, Gain level, etc.	Dedicated menu according to detector type enrolled
<b>Radio Zone Module</b>	Select device type " ISM " for RF devices or "DECT" for DECT devices.	

## Zone Configuration –features & options examples:

### Wireless PIR Detector



#### Available Options

LED(s) state: Activation or not of the LED indicators

Supervision: Time period between each supervision in minute (from 1 to 30)

Pet Immunity: Activation of up to 25Kg Pet immunity

Number of Pulses: Pulse count for each motion detection


Sensitivity : PIR Sensitivity

### Wireless Door / Window Magnet SH-MAG2

#### Available Options

LED Enable: Activation or not of the LED indicators

Supervision: Time period between each supervision in minute (from 7 to 30)




**Internal Switch:** Activation of the internal reed switch

**External switch:** Activation of the internal terminal block (to connect external wire device)

**Logic of Switches:** Alarm trigger according AND / OR Mode of both internal and external state.

### Wireless Flood Detector




#### Available Options

**LED Enable:** Activation or not of the LED indicators

**Supervision:** Time period between each supervision in minute (from 7 to 30)

### Wireless SH- Camera PIR



#### Available Options

**LED(s) state:** Activation or not of the LED indicators

**Pet Immunity:** Activation of the up to 25Kg Pet immunity

**Number of pulses:** Pulse count for each motion detection (1,2 or3)

**Sensitivity:** Sensitivity of the PYRO sensor

**Picts per set:** Number of pictures sent in case of alarm event

**JPEG Quality level:** Quality of the picture (from 20% to 90%)

**Picture resolution & color:** Selection between: QVGA B&W (320x240), VGA B&W (640x480), QVGA Color (320x240), VGA Color (640x480)

**Camera State:**

**Pulse Direction Mode:**


**Infra LED:**

**Conf Time B/W 1<sup>st</sup> and 2<sup>nd</sup> Pulses:**

**Time B/W 1<sup>st</sup> and 2<sup>nd</sup> Pulses:**

**Time B/W 2<sup>st</sup> and 3<sup>nd</sup> Pulses:**

**JPEG mode:** Regular or Differential (Video Motion Detection)



**Pict Rate:** Time laps between alarm pictures

**Diff JPEG ratio:** Sensitivity of the Video Motion Detection (High or Low)

**Hold off (sec):** Wait time between 2 detections and pictures (*between 30 to 120 sec*)

**Contrast enhancement:** Contrast emphasis of the picture

**Sharpness enhancement:** Sharpness of the picture

Re-trigger

Parameter	Description	Default Configuration
<b>Zone re-trigger count</b>	Each Zone has its own alarm re-trigger count. A value of 0 programmed at this location results in unlimited alarms for that zone during an armed period but a count of 1-15 will shut down the zone once the programmed count has been reached. Disarming the alarm will reset this count. In case the zone is assigned to more than one area, this counter should be multiplied by number of areas (e.g. if zone 1 belongs to A1 & A2, to achieve re-trigger count = 3, you will need to enter re-trigger count = 6, because alarm in each area will increment the counter and common number of re-trigger counts will multiply).	Value "0"

Zone # : Beeps To Keypads

Parameter	Description	Default Configuration
<b>Armed Zone Alarm Beeps to Keypads</b>	If an Area is Armed and a zone assigned to that Area activates, the zone can sound the buzzer at selected keypads for local alarm signaling. This location assigns zone alarm beep to a keypad for alarms that occur when in the Full Armed State.	Disable

<b>Stay Mode Zone Alarm Beeps Keypads</b>	If an Area is Stay Mode Armed and a zone assigned to that Area activates, the zone can sound the buzzer at selected keypads for local alarm signaling. This location assigns zone alarm beep to a keypad for alarms that occur when in Stay Mode is Armed	disable
<b>Zone 24 hour alarm beeps to keypads</b>	If a zone programmed as a 24 Hour type and it activates, the zone can sound the buzzer at selected keypads for local alarm signaling. If the zone is a standard 24 hour type or Fire type the keypad buzzer will sound until reset by a User but if it is an Auto-reset type the keypad buzzer will reset when the input clears	disable
<b>Chime Zone Alarm Beeps Keypads</b>	If a zone programmed as a Chime zone and it activates, the zone can sound the buzzer at selected keypads for local alarm signaling. The duration of the Chime beep programmed. The Chime function also can be locally disabled at each keypad individually if not required.	disable
<b>Zone Tamper Alarm Beeps Keypads</b>	Zone tamper can beep the keypad buzzer at individual keypads	disable
<b>Radio Supervise Alarm Beeps Keypads</b>	If a zone is programmed as a radio zone and that type is actively monitoring the supervision signal, a supervise signal failure from the detector alarm can sound the buzzer at selected Keypads for local alarm signaling	disable
<b>Zone Sensor-watch Alarm Beeps Keypads</b>	If the zone is programmed for inactivity monitoring and it is not operated within the time set at a 'Sensor-watch' alarm will be generated. A 'Sensor-watch' failure from the detector can sound the buzzer at selected Keypads for local alarm signaling	disable
<b>Armed zone entry delay beeps to keypads</b>	If the alarm is Armed and a delay zone triggers the entry delay it can also beep the keypad buzzer to warn that the entry delay is counting down and the alarm should be turned off	disable
<b>Stay mode entry delay beeps to keypads</b>	If Stay Mode is Armed and a Stay Mode delay zone triggers the entry delay it can also beep the keypad buzzer to warn that the entry delay is counting down and the alarm should be turned off	disable

## Outputs

### Settings

Parameter	Description	Default Configuration
<b>Invert Output (for wire output only)</b>	This option is used to invert the normal state of the output. The panel uses open collector transistor switches, and the default state of all outputs is off (open). When in alarm the transistor is turned on and the output goes low (0V). The invert option reverses this function.	Disable
<b>Lockout Output</b>	This option is used to limit the output to one operation per arming period.	disable
<b>Pulse Output on Kiss-off after Arming</b>	This option will cause the Output to short single pulse when any area is armed and the message has been kissed off by monitoring company.	disable
<b>Disable Output during Disarm</b>	This option will cause the Output to be disabled when all areas in DISARM state. It is designed to keep audible alarms silent when the full system disarm, but part of alarms (like Panic or Fire alarm) still turns audible alarms to on regardless of this setting.	disable
<b>Enable Monitoring of output</b>	If this option is enabled, the control panel monitors the status of the outputs by voltage level for wired outputs or coming supervision messages for wireless outputs. If disabled - monitoring the state of the outputs will disabled	disable
<b>Enable Mute</b>	Disable the siren sound only	disable

### Output Type

Parameter	Description	Default Configuration
<b>Output is constant</b>	The output will change its state when an alarm occurs	Disable

## Time Zone Assignment

Parameter	Description	Default Configuration
<b>Time Zone Assigned to Output</b>	If a time-zone is assigned to an output it will turn the output on when the time-zone starts and turn the output off when it finishes.	disable

## Signals to Output

Parameter	Description	Default Configuration
<b>Mains Fail to Output</b>	This option is used to assign a Mains Fail alarm to an Output	Disable
<b>Fuse Fail to Output</b>		*Not in use
<b>Batt Low to Output</b>	This option is used to assign a Battery Low alarm to an Output	disable
<b>Monitor output fail to Output</b>	This option will cause the Output to short single pulse when any area is armed and monitoring company has kissed off the message.	disable
<b>Output tamper alarm to Output</b>	This option is used to assign a Output tamper alarm to an Output. When output tamper alarm occurs, any output can be turned to on	disable works in ARM mode only (Shmulik decision )
<b>Communication fail to Output</b>	This option is used to assign a Communication Failure alarm to an Output	disable
<b>Radio Zone Supervised Fail to Output</b>	This option is used to assign a Radio Detector Supervisory Fail alarm to an Output	disable
<b>System tamper to output</b>	This option is used for indication of panel tamper alarm by specified Output. This option works in arm or stay arm state only and The Output turns to on.	
<b>Sensor-watch to output</b>	This option is used to assign a Sensor-Watch alarm to an Output. A Sensor-Watch alarm occurs when a detector has not operated within a set period of time. Zone sensor watch time can be set in zone level per each zone(in minutes)	
<b>Duress Alarm to Output</b>	Duress Alarm can be assigned to an Output or multiple Outputs. This can be used to operate an audible or visual alarm connected to the Output.	

<b>Walk Test Pulse to Output</b>	When the panel is in Walk-test Mode, this option assigns a one single pulse (one chirp) to the Output every time a zone is triggered.	disable
<b>Pendant Panic, Fire, Medical Alarm to Output</b>	A Pendant Panic Alarm can be assigned to an Output or multiple Outputs. This can be used to operate an audible or visual alarm connected to the Output	disable

#### Timing

Parameter	Description	Default Configuration
<b>Output on delay time (seconds)</b>	The 'On' delay allows the operation of the Output to be delayed by the time programmed at this location. If set to '0' there will be no on delay and the Output will operate the instant, it is turned on. The time range is 0-36000 seconds.	Disable
<b>Output pulse time (1/10h seconds)</b>	Output Pulse Time affects the time an output turns on when the pulse timer is used on the Output . The pulse time is in 1/10th second increments so that very quick timing can be achieved. The maximum value that could be assigned to is 36000 which corresponds to 1 hour. The parameter valid for wired outputs only.	N/A not in use
<b>Output reset time (seconds)</b>	The Reset time affects the time the output turns on in case of alarm state. The time range is 0-36000 seconds.	disable

#### Add Output

Parameter	Description	Default Configuration
<b>Learn Radio Output / Serial number</b>	Insert Device's ID and type	Disable
<b>Delete Radio Output</b>	Delete existing radio output from memory	disable
<b>Output config</b>	This function set remotely the radio output parameters according different output devices types such as led on/off, sounder on/off, led and sounder timeouts, and Loudness etc.	disable
<b>Radio Output Module / Link type</b>	Select device type " ISM" , "DECT" or " ISM Extender" (RL1, RL2)	disable

Parameter	Description	Default Configuration
<b>Alarm from zones</b>	If an Area is Armed and a zone assigned to that Area activates, the zone can trigger selected Outputs for local alarm signaling. This location assigns Zones to Outputs for alarms that occur when in the Full Armed State	No Outputs selected
<b>Stay Alarm from zones</b>	If an Area has Stay Mode Armed and a zone assigned to that Area activates, the zone can trigger selected Outputs for local alarm signaling. This location assigns Zones to Outputs for alarms that occur when Stay Mode is Armed	No Outputs selected
<b>24H Alarm from zones</b>	If a zone is programmed as one of 24 Hour type zone and if it is open then the selected output(s) is activated for local alarm signaling. In case of standard 24-hour zone the output will be active for the full reset time. In case of 24-hour auto-reset zone the output is deactivated when the reset time expires or if the zone is closed. If a zone is a 24-hour fire zone then the output will pulse at a rate equals to the pulse time for that output.	No Outputs selected
<b>Tamper from zones</b>	Zone tamper can trigger selected output(s) for local alarm signaling.	No Outputs selected
<b>Chime alarm from zones</b>	If a zone is programmed as a Chime zone and it activates, the zone can trigger selected Outputs for local alarm signaling. The output will operate for the Chime to Output time at location. The zone must clear before the output can be activated again	No Outputs selected
<b>Entry delay from armed zones</b>	If the panel is Armed and a delay zone triggers, the entry delay it can also turn an Output to ON to warn that the entry delay is counting down and the alarm should be turned off	No Outputs selected
<b>Stay entry delay from zones</b>	If Stay Mode is Armed and a delay zone triggers the entry delay it can also turn an Output to ON to warn that the entry delay is counting down and the alarm should be turned off	No Outputs selected
<b>Near Alarm from zones</b>	If zones are programmed for near and verified alarms, it is also possible to get an indication of a near alarm from any of the 16 outputs using this program location. A near alarm is the first alarm during an armed period	No Outputs selected

<b>verified alarm from zones</b>	If zones are programmed for near and verified alarms, it is also possible to get an indication of a verified alarm from any of the 16 outputs using this program location. A verified alarm is the second alarm from a different zone to the one that caused the near alarm and must happen within 45 minutes of the near alarm	No Outputs selected
----------------------------------	---	---------------------

### Chime Alarm Reset By

Parameter	Description	Default Configuration
<b>Signal</b>	The output will change its state when an detection/restore occurs	Not selected
<b>Time</b>	The output will change its state and stay on by time set in output reset time value	Not selected
<b>Retrigger Time</b>	Additional time will be added set in output reset time in case of re-trigger	Not selected

### Extenders

#### Advanced Configuration

Parameter	Description	Default Configuration
<b>Add Extender</b>	The SH-IO 2x2 is an external two-way wireless device, two Inputs (optional 2 zones per one input by EOL resistors) and 2 Output Relays module. <u>Extender registration :</u> <ul style="list-style-type: none"> <li>- Link type : ISM</li> <li>- Serial number : Device's ID No.</li> <li>- Device type: IO 2x2 Relay Board</li> </ul>	
<b>Extender Config</b>	<ul style="list-style-type: none"> <li>- set Extender inputs type: N/O, N/C , single zone device or double zone devices</li> <li>- set Extender outputs mode : N/C or N/O</li> <li>- use the Extender instructions manual for connecting and setting EOL resistors and working mode.</li> </ul>	Led : enable Input : 1, 2 Both N/C Output : 1, 2 Both N/C

<b>Delete</b>	This button is used to delete the device from the system	
---------------	--	--

### [Report Channels](#)

Click on a report channel 1-8 to display its options.

Channel Type

Parameter	Description	Default Configuration
<b>TCP_IP</b>	Set channel type as TCP/IP Need to set Ethernet enabled to use this type of channel	<b>Note:</b> The channel #8 is dedicated to the CrowCloud™™ connection; please do not change these settings.
<b>Wi-Fi</b>	Set channel type as Wi-Fi. Need to set Wi-Fi enabled to use this type of channel	
<b>GPRS</b>	Set channel type as 4G  Need to set 4G IP enabled to use this type of channel in setting "Communication" → "GSM" ( <i>see below in paragraph "Communication"</i> )	
<b>SMS</b>	Set channel type as SMS Text Messages	
<b>VOICE</b>	Set channel type as a VOICE for voice Messages announcement to telephone when the system is in ARM mode or to a local voice devise when the system is in the DISARM	

Settings

Parameter	Description	Default Configuration
<b>Channel is active</b>	This option activates or deactivates a report channel for operations.	Channel #8 activated only

<b>Destination address</b>	<p>Can be up to 7 phone numbers (for channels 1-7 defines as GSM voice/SMS) or 7 server addresses (for channel 1-7 defined as TCP-IP/WiFi/GPRS).</p> <p>The length is up to 32 characters long (digits only for phone numbers and characters/digits for server address).</p>	No address specified
<b>Protocol</b>	<p><u>Defines one of the protocol types for each report channel:</u></p> <ul style="list-style-type: none"> <li>• Crow (crow's receiver server is required at the CMS server)</li> <li>• SIA-09(ADM-CID)</li> <li>• SIA-09(SIA-DCS)</li> <li>• SIA Null – event time control programmable reporting options</li> </ul>	Crow predefined
<b>Port</b>	Defines report protocol port (up to 5 digits)	4705 predefined (Crow)
<b>Channel Backup</b>	This channel will be activate if the main channel has failed to open connection or deliver a message.	No channels selected
<b>Failed channel (1-7) restore time (Min.)</b>	If either channel has failed to deliver messages, it will be temporarily disable for a period defined by this parameter. During this time, the corresponding backup channel will be use.	3 minutes
<b>SIA null-event time (seconds)</b>	The C.P and CMS may be configured to supervise the connection When supported and enabled, the C.P shall periodically send the Null Message to the CMS. The supervision interval shall be configurable over a range of 1 seconds to 900 seconds.	20
<b>Encryption code</b>	The C.P may send an encrypted or an unencrypted Null Message to permit supervision of the link between the premises and the central station.	0x32

Area account numbers

Parameter	Description	Default Configuration
<b>Account Number</b>	<p>When system sends a report to a monitoring station there must be a unique account number programmed to identify the panel. There is an account code for each area.</p> <p>The account code is 4 digits. Each digit can be a number from 0-9 as well as the special characters B, C, D, E &amp; F. For SMS report channels no need to define the account number.</p>	All account at "0" except the channel #8 with account "8000" for CrowCloud™ connection

Reporting Options

Parameter	Description	Default Configuration
<b>Report Mains Failure</b>	If this option is selected the panel will report a Mains failure after the report delay time has expired (see "Clock and Timers" → "Delays")	All channels selected
<b>Report Battery Low</b>	If this option is selected the panel will report a Battery Low	All channels selected
<b>Report Communication Fail</b>	If this option is selected the panel will report a Communication failure.	All channels selected
<b>Report System Tamper</b>	If this option is selected the panel will report a Tamper Alarm on the tamper panel is triggered	All channels selected
<b>Report Keypad Tamper</b>	If this option is selected the panel will report a Tamper Alarm from a keypad fitted with a tamper switch or a wrong code alarm from a keypad	All channels selected
<b>Report Zone Tamper</b>	If this option is on the panel will report a Zone Tamper Alarm	All channels selected
<b>Report Zone Trouble</b>	If this option is on the panel will report a Zone trouble Alarm	
<b>Report Duress Alarm</b>	If this option is on the panel will report a Duress Alarm	All channels selected
<b>Report Panic Alarm</b>	If this option is on the panel will report a Panic Alarm generated by keypad or RMT (pendant)	All channels selected
<b>Report Manual Fire Alarm</b>	If this option is on the panel will report a Keypad generated Fire Alarm	All channels selected
<b>Report Manual Medical Alarm</b>	If this option is on the panel will report a Keypad generated Medical Alarm	All channels selected
<b>Report Zone Bypasses</b>	If this option is on the panel will report a Manual or Auto Bypass on a zone	All channels selected
<b>Report Arm-Disarm</b>	If this option is on then all Arm/Disarm signals will be reported to a Monitoring Station	All channels selected
<b>Report Stay Mode Arm-Disarm</b>	If this option is on then all Stay Mode Arm/Disarm signals will be reported to a Monitoring Station	All channels selected


<b>Report Disarm only after an Activation</b>	If this option is on, the panel will not normally send an Arm/Disarm signal to the monitoring company, however, if a zone alarm occurs the panel will send a Disarm following the disarming of the panel to show it has been turned OFF by a valid user	No channel selected
<b>Report Stay Disarm only after an Activation</b>	If this option is on, the panel will not normally send a Stay Mode Arm/Disarm signal to the monitoring company, however, if a zone alarm occurs the panel will send a Stay Mode Disarm following the disarming of the panel to show it has been turned OFF by a valid user	No channel selected
<b>Report Access to Program Mode</b>	If this option is on the panel will report a Contact ID code to indicate that either Client or Installer program Modes have been accessed	All channels selected
<b>Report Zone Restores</b>	If this option is on the panel will report all zone restores. If this option is turned off the panel will only report the alarms	All channels selected
<b>Report Delinquent</b>	If the panel has been configured for Delinquency monitoring and an area has not been armed for the time set at, a Delinquency Alarm will be sent to the Monitoring Station	All channels selected
<b>Report Radio Battery Low</b>	If this option is on the panel will report a Battery Low from any radio zones that have the battery status monitored	All channels selected
<b>Report Supervised Radio Alarm</b>	If this option is on the panel will report a Supervised radio Alarm.	All channels selected
<b>Report Zone Sensor-watch Alarm</b>	If this option is on the panel will report a Zone Inactivity (Sensor-watch) Alarm.	All channels selected
<b>Report Latchkey Disarm</b>	When this option is turned ON and the panel was armed in Latchkey Report Mode, at Disarming by a non-latchkey user the specified latchkey disarm report will be sent via voice or SMS report channel to user, marked as latchkey mode user.	All channels selected
<b>Report Communication Interference Detected</b>	If the radio receiver detects Communication Interference (Jamming) of the radio frequency, the panel can report this event to the monitoring station if this option is turned on	All channels selected
<b>Report Output Fail</b>	If this option is on and a fault is detected on the output, a report will be sent to the monitoring station if Contact ID is set as the reporting format	All channels selected
<b>Report Tests</b>	If this option is selected, the panel can send automatic test connections, but if test connections are not required, they can be disabled by turning this option off.	All channels selected
<b>Report Stay Mode Zone Alarms</b>	If this option is on, the panel will report zone alarms in Stay Mode	All channels selected

<b>Report output changed</b>	The changing output state will be reported via SMS reporting to the user	All channels selected
<b>Report Peripheral Tamper</b>	If this option is on the panel will report a Tamper Alarm from a peripheral module (extender module or radio output) fitted with a tamper switch from a peripheral module	All channels selected
<b>Report Zone Confirmed Alarm</b>	If this option is on the panel will report a Zone Confirmed (Near and Verified) Alarms.	All channels selected


## Keypads

### Radio Keypads

#### SH-KP Icon Keypad Overview



The SH-KP is an optional two-way wireless keypad with built-in proximity RFID tag reader compliant with RFID tags including variation of millions ID combinations and numerical keypad.



For RFID control, please use access tag. Press the key "Enter" and serve the tag.

For learning procedure, please refer to the paragraph "Radio Keypad" below.

For additional information on the SH-KP please refer to its manual.

Please note that there is another SH-Keypad PRO with more features and options, for more information please refer to SH-KP-PRO manual.

### Settings

Parameter	Description	Default Configuration
<b>Enabled Beeps and LED indication</b>	Enable /Disable audible beeps and LED indication light on the Keypad	Enable
<b>No armed indication</b>	This option allows the screen information on a keypad to be turned off when the panel is in the Armed or Stay Armed state. The screen return to the normal state on disarming of the system	Disable
<b>On keypad panic alarm call voice</b>	A feature must be enabled in the check box if we want a two-way voice call in the event of a panic from a panic Keyped device. In order to establish a two-way voice call, we must ensure at least one voice device (AVM) is set up in the system. So that the call will establish between the voice device and the destination end user's phone.	Relevant for SH-KP-PRO
<b>Keypad emergency alarm</b>	When this option is checked / activated, the panic event is replaced by an emergency event and also the CID to the monitoring statin alarm is different	Relevant for SH-KP-PRO

### Area Assignment

Parameter	Description	Default Configuration
<b>Keypad Assigned To Area</b>	This option assigns Area to keypads. If a keypad assigned to one area, only it can Arm or Disarm only that area and show states only for this area.	Area 1

### User Assignment

Parameter	Description	Default Configuration
<b>Keypad control on users</b>	Any user can assigned to operate at certain Keypads. This option controls whether a code or access tag User Can Arm/Disarm from certain keypads.	All users

### Output Assignment

Parameter	Description	Default Configuration
<b>Keypad is linked to outputs</b>	A Keypad can be assigned to an Output or multiple Outputs. If a Keypad is not assigned to an Output a User cannot turn that Output On or Off from the Keypad. This feature is useful when using the access control features of the panel, eg a User may be allowed to operate more than one Output with their code but they will be limited to just the Output assigned to the Keypad they are using	All users

### Alarm to Output

Parameter	Description	Default Configuration
<b>Keypad medical alarm to outputs</b>	A Keypad generated Medical Alarm can be assigned to an Output or multiple Outputs. This can be used to operate an audible or visual alarm connected to the Output	
<b>Keypad panic alarm to outputs</b>	A Keypad Panic Alarm can be assigned to an Output or multiple Outputs. This can be used to operate an audible or visual alarm connected to the Output	
<b>Keypad fire alarm to outputs</b>	A Keypad generated Fire Alarm can be assigned to an Output or multiple Outputs. This can be used to operate an audible or visual alarm connected to the Output	
<b>Wrong Code Alarm to Output</b>	If someone is attempting disarm the alarm by trying various code combinations and they enter in 5 wrong codes the panel will go into a 'Wrong Code' tamper alarm. The Alarm can be assigned to an Output or multiple Outputs. This can be use to operate an audible or visual alarm connected to the Output. A correct code entry will reset the tamper alarm	N/A
<b>Keypad tamper alarm to outputs</b>	If the keypad has a Tamper Switch fitted and this switch activated, the Tamper Alarm can be assigned to an Output or multiple Outputs. This can be used to operate an audible or visual alarm connected to the Output	

## Add Keypad

Parameter	Description	Default Configuration
<b>Link Type</b>	Link type is "ISM "	
<b>Serial number</b>	Insert Device's ID number	
<b>Device Type</b>	Select keypad type 1.Led Indication Keypad 2. Advanced Keypad 3. Pro Keypad	
<b>KeyPad Configuration</b>	Setting the keypad config. Please refer to device's manual	Enable
<b>Delete Keypad</b>	Removing previously paired keypad from the system	

## Communication

### Remote Access

Parameter	Description	Default Configuration
<b>Servers Password</b>	It is defined up to 8 characters password for remote connection (CrowCloud™ and Mobile applications)	12345678
<b>Server 1-4 Address</b>	This parameter defines IP-address or DNS name of the remote access server.	mediator.CrowCloud.xyz <i>(CrowCloud™ server address)</i>
<b>Server 1-4 Port</b>	This parameter defines the port on remote access server the control panel using fore registration procedure.	4705 <i>(CrowCloud™ server port)</i>

### Communication Options

Parameter	Description	Default Configuration
<b>Time to First Test Connection</b>	Define the time of first automatic test connection.	00
<b>Test Connection Time Period</b>	Time period between successive automatic test connections	0
<b>Incoming Phone numbers for remote control Phone</b>	Setting of up to 8 assigned phone numbers which are authorized for control the system remotely via DTMF control	Empty
<b>Listen only</b>	Used to hear audio from voice device microphone , and no activation of voice device speaker	Empty
<b>Use Hash for Confirmation</b>	If the panel is set to use the Voice reporting call or voice messages announcements option, you can simply kiss-off (Acknowledge) the call/alarm by pressing the <#> button on the telephone right after answering the call, otherwise the call will disconnect after 30 sec. If the parameter is not set, the voice call will continue till remote phone or the originator will close connection (hangs down).	Enable
<b>Wait to Hash Timeout (seconds)</b>	This is the time period required to press the Hash key after answering a call from the control panel / voice device otherwise the call will be disconnect at the end of this time.	200 (seconds)

<b>Dial timeout ( seconds)</b>	Dial Timeout is the maximum amount of time a dial will wait for a connect to complete, if there is no connect completed, a dial will terminated.	200
<b>Retries panic number</b>	Number of Dial Attempts After a panic event, the dial attempt will be made only after the end of the Dial timeout of the previous dial if no one answered the call.	0
<b>Auto answer</b>	If the parameter is set, Automatically answer by the voice device devices when receiving a call from a phone without accepting a call by pressing a key in the voice box.	
<b>Listen only</b>	If the parameter is set, When receiving a call from a phone, the voice device will automatically answer the call without a ring or indicator light and without open the speaker, but only the microphone will be open for the caller (remote control phone must be programmed)	

#### TCP/IP

Parameter	Description	Default Configuration
<b>Ethernet Enabled</b>	If this option selected, the Ethernet connection is Enable.	Enable
<b>DHCP Enabled</b>	If this option selected, the DHCP is Enable. The server will automatically assign an IP address to the control panel.	Enabled
<b>Static IP</b>	If DHCP is Disable, the control panel must be manually configure with an IP address, subnet mask, Panel, DNS server.	Empty
<b>Subnet Mask</b>	The network subnet mask for defined static IP address.	Empty
<b>Gateway</b>	IP Address of the router/server.	Empty
<b>DNS Server</b>	The network DNS server address for defined static IP address.	Empty
<b>TCP/IP Port for Remote Control</b>	The number of incoming TCP/IP port using for remote control applications.	3064

#### GSM

Parameter	Description	Default Configuration
<b>GSM IP Enabled</b>	If this option is on, the GPRS/3G Data is Enabled. This communication method suits for Data connection to Monitoring Station or Server.	Enabled
<b>GSM SMS Enabled</b>	If this option is on, the GSM SMS is Enabled.	Enabled
<b>PIN Code</b>	GSM PIN code number according to GSM network requirements, up to 8 digits length.	No PIN Code
<b>GSM User</b>	GPRS user according to APN GSM network requirements.	Empty

<b>GSM Password</b>	GPRS Password according to APN GSM network requirements.	Empty
<b>GSM APN</b>	GPRS APN access point name according to your cellular provider.	"internet"
<b>USSD Code</b>	Unstructured Supplementary Service Data (USSD) is a protocol used by GSM cellular telephones to communicate with the service provider's computers, using for prepaid callback and mobile-money services. The parameter contains 3 decimal digits.	0
<b>System Language</b>	Used to change the language of SMS messages	
<b>Voice Language</b>	Used to change the language of Voice messages	
<b>Low RSSI alert (-110 ÷ -50)</b>	Low RSSI Alert RSSI measures the strength of a radio signal. Any RSSI value lower than the programmed RSSI value will alert about poor signal strength.	

#### Wi-Fi

<b>Parameter</b>	<b>Description</b>	<b>Default Configuration</b>
<b>Wi-Fi Enabled</b>	If this option selected, the Wi-Fi connection is Enable.	Disabled
<b>SSID</b>	The wireless network name	Empty
<b>Security Type</b>	Select the security type of your Wi-Fi network	"Open" – No Encryption
<b>Password</b>	Password of the wireless network you want to connect to.	Empty

**What is DECT ULE?**

ULE addresses Ultra-Low Energy application requirements by introducing optimized communication methods. Identified with low power consumption, low latency, long range, moderate data rate and value-added complementary voice capabilities, ULE is the best-of-class technology, which represents the next evolution in home networking.

ULE is based on DECT (Digital Enhanced Cordless Telecommunications) which is the de-facto standard for residential and business cordless phone communications worldwide.

DECT ULE is an SW protocol extension of the standard DECT, these devices can be easily support DECT ULE for Home Automation and Security/Monitoring.

DECT ULE: the perfect combination of long battery lifetime, high data rate, low cost and long transmission range.

Frequency Allocations:

- Europe: 1880-1900 MHz
- China: 1900-1920 MHz
- Japan: 1893-1906 MHz
- Latin America: 1910-1930 MHz
- US & Canada: 1920-1930 MHz

Parameter	Description	Default Configuration
<b>DECT Enabled</b>	If this option is selected, the DECT Module Activated.	Enabled
<b>DECT Contact Number</b>	Phone numbers of the contact people called from the Audio Panic DECT button	Empty
<b>Learn DECT Device</b>	DECT detector must be enroll into the panel before it can be use. Click this button to start DECT pairing process	-
<b>Delete DECT HAN Device</b>	Removing DECT device from the system. Select the device you want to delete and press the button Confirm deletion and save the configuration	ID of the DECT device
<b>Delete DECT HS Device</b>	Click this button to delete DECT Panic Button	Empty
<b>DECT PIN Code</b>	GSM pin code number according GSM network requirements, up to 8 digits length.	Empty

Crow Electronic Engineering Ltd. Is an active contributor to the ULE Alliance with a full range of DECT ULE products



Parameter	Description	Default Configuration
<b>Starting RF Channel</b>	The PANEL supports up to 5 frequencies to prevent jamming. You can choose frequency range from 1 to 5.	1
<b>Learn Repeater</b>	Enter the unique ID of the device Press Done and Save the configuration	-
<b>Delete Repeater</b>	Click this button to delete the selected wireless repeater	-

## Time Zones

### Settings

Parameter	Description	Default Configuration
<b>Time Zone Start Time</b>	The Time-zone start time is when the time-zone begins. The time using for arm of area(s), turn output(s) to ON state and activate rights of specified user(s). There are 8 time-zones that can be programmed. Indications in User Cloud: <b>Area 1 will Arm by Time Zone 1 in 30 minutes</b> <b>Area 1 Armed by Time Zone 1</b>	Empty
<b>Time Zone End Time</b>	The Time-zone end time is when the time-zone finishes. The time using for disarm of area(s), turn output(s) to OFF state and deactivate rights of specified user(s). There are 8 time-zones that can be programmed. Indications in User Cloud: <b>Area 1 Disarmed by Time Zone 1</b>	Empty
<b>Time Zone Day</b>	The Time-zone days are the days of week that the time-zone will be active. You can select any combination of the days from Sunday till Saturday. There are 8 time-zones that can be programmed.	Empty
<b>Holidays</b>	It is possible to pre-program up to 8 holidays. Holidays can override the time-zone function on the programmed day. For example, if an output was automatically controlled by a time- zone, the pre-programmed holidays can stop the output from turning on or off on a holiday. A holiday consists of a single day programmed by date. The holiday begins at the start of the day (00:00:00) and finishes immediately before midnight (23:59:59) on the programmed date. Holidays can programmed in any order (although for simplicity it is recommend that they programmed in chronological order) and the panel automatically removes them once the day ends. If you wish to remove a programmed holiday, you should to clear the date field.	Empty



Time zones holidays:

Parameter	Description	Default Configuration
<b>Date Format</b>	Date format selection options	

Area assignment

Parameter	Description	Default Configuration
<b>Time zone assign to Areas</b>	If area assigned to time-zone it will automatically armed when time-zone starts and disarmed when it finishes. You can assign more than one time-zone to each area. If assigning multiple time-zones you should insure that they do not overlap as this could cause confusion.	
<b>Time zone STAY Armed Areas</b>	The parameter is used for the separation time zone possibility to made ARM and STAY ARM operations. If the parameter marked when time zone will start, the corresponded area will STAY armed. Otherwise, when time zone will start the area will ARMED.	NOTE: For STAY ARM to work , ARM must be checked as well

User Assignment

Parameter	Description	Default Configuration
<b>Time zone control on Users</b>	When the user is controlled by time zone, its keypad code, access tag and pendant deactivated all the time, when the time zone is not started or finished. Only when the time zone is started, the user can perform actions in the system in accordance with its rights as defined by configuration.	

Output Assignment

Parameter	Description	Default Configuration
<b>Time zone assigned to Outputs</b>	If a time-zone is assigned to an output it will turn the output on when the time-zone starts and turn the output off when it finishes.	

## Miscellaneous

### Chime Control

Parameter	Description	Default Configuration
<b>Chime Alarm Beeps to Keypad</b>	If a zone is programmed as a Chime zone and it activates, the zone can sound the buzzer at Selected keypads for local alarm signaling. The duration of the Chime beep is programmed. The Chime function can also be locally disabled at each keypad individually if not required	Not selected

### User Options

Parameter	Description	Default Configuration
<b>Cancel Handover Zone Function in Stay Mode</b>	If this option is selected, any zone programmed with the handover feature will act as a normal delayed zone during Stay mode (i.e. the handover feature will be ignored).  The zone will still have the normal handover feature during the full arm state.	Not selected

## Panel Options

Parameter	Description	Default Configuration
<b>Installer Code</b>	This code is used to enter into full Installer Program mode. This code can only be changed while in Installer Program Mode. The Installer Code must be between 4-8 digits in length	000000
<b>Duress Digit</b>	A Duress alarm is created when the alarm system is disarmed by increasing the last digit of the original user code by 1  example : the original code is 1234 , to activate the duress code the code should be 1235 ( 123X x+1 )	
<b>Disable mains fail test</b>	If the panel must be run off a DC supply or the Mains supply can fail regularly, this option disables the mains voltage monitoring to prevent mains fail alarms from occurring	Not selected
<b>Images link</b>	This feature used when panel uses the report channel SIA-DC09 ( SIA-09 DCS) protocol type for CMS, Checking this box consolidates the images links associated with the same event for view created due to camera detection	
<b>Buzzer Enable</b>	If this option is enabled it means that the buzzer panel is in active mode	disable
<b>Buzzer Reset Time</b>	Buzzer Reset Time in minutes	1 minute
<b>Cannot arm if the system low battery or AC Fail</b>	if this option is selected, the panel cannot be armed if the panel battery is low or the AC has failed.  When the battery is fully charged or the AC has returned, the panel can then be armed.  If this option not selected, the panel can be armed during these fault conditions.	Not selected
<b>Cannot arm when keypad fault</b>	if this option is checked and a missing keypad alarm is present, the panel cannot be armed until the keypad has been reinstalled.	
<b>Cannot arm when communication fault</b>	If this option is selected and the control panel has detected a communication fault (Ethernet or GSM/GPRS) the panel cannot be armed.  To reset the failure the line must be re-instated to allow arming again.	Not selected

<b>Keypad locks for 90 sec after 5 code attempts</b>	After 5 incorrect codes are entered the keypad will be locked out for 90 seconds	Enable
<b>Code must be 4-8 digits long</b>	If this option is selected, all user codes, installer code, time zone passwords and remote access password must be between 4-8 digits long. If it is not selected, the minimal length of the code is one digit.	Not selected
<b>Enable keypad tamper</b>	if this option is checked the keypad tamper will be enable and can cause to keypad tamper alarm if keypad removed from the wall. If this option is OFF, then the keypad tamper will be disabled, opening or removing the keypad from the wall will not cause to tamper alarm on panel.	
<b>Enable Output Tamper</b>	Monitoring of Tamper alarm indication for any device which is connected to Control Panel's output.	Selected
<b>Enable panel tamper</b>	if this option is checked the Panel tamper will be enable and can cause to Panel tamper alarm.	
<b>Send picture after disarm</b>	Continue send picture after disarm	
<b>Max report count</b>	The maximum number of log reports from any single source. The value is limited from 3 to 10.	10
<b>Panel title</b>	This is the name you give to your control panel to identify it (Ex: Home)	MiniGW
<b>License time</b>	Time period to permit the user control panel and use all activity	Not selected
<b>EN Compliance</b>	Enable/Disable EN 50131 Compliance	Not selected
<b>UL Compliance</b>	TBD	

#### Timers And Delays

#### System Date and Time

Parameter	Description	Default Configuration
<b>Daylight Saving</b>	If you are in Daylight Saving Time when the alarm system is installed, you MUST turn this option on so that the panel knows that Daylight Saving Time is currently active. Failure to do this will not allow the clock to automatically adjust to the correct time when Daylight Saving Time Ends	Empty
<b>GMT</b>	Time zone starts from Greenwich Mean Time (GMT 0)	2

## Timers

Parameter	Description	Default Configuration
<b>Radio Zone Supervised Time (minutes)</b>	If a radio detector is capable of sending regular supervisory signals to the panel and the zone type is set for 'Supervised Signal Active', this timer sets how long a period has to elapse with no received transmissions before a supervisory failure alarm is generated. The time range is 1-255 minutes.	63
<b>Two Trigger Time (seconds)</b>	If a zone is set to two trigger, the zone has to cause an alarm twice within the two trigger time period to cause an alarm. If multiple zones are set to two trigger, an alarm will be generated if two zones trigger once each within the two trigger time period. If a two trigger zone goes into alarm but remains in alarm for longer than the two trigger time period (ie detector failure or cable cut) an alarm will be generated. The time range is 5-255 seconds.	20

## Delays

Parameter	Description	Default Configuration
<b>Alarm Reporting Delay (seconds)</b>	If this address is set to 0, there will be no report delay. If it is set to any value other than 0 then a delay equal to the programmed value will stop the panel from reporting an alarm until this delay time expires. While the timer is active certain outputs can be disabled. Once the timer has expired it will not start again, the panel must be disarmed then armed to reset the timer. The value in seconds, maximal limit is 255 seconds.	0
<b>Mains Fail Reporting Delay (seconds)</b>	If a Mains Failure occurs this timer delays the reporting of Mains Failure to a Monitoring Station. If the mains power returns before the timer expires, then no report is sent. If Mains Failure is assigned to an output, this delay must expire before the output will turn on. The value in seconds, maximal limit is 3 hours (10800 seconds).	900
<b>Communication Fail Reporting Delay (seconds)</b>	If a Communication Fail occurs this timer delays the reporting of Communication Fail to a Monitoring Station. If specified communication path returns before the timer expires, then no report is sent. If Communication Fail is assigned to an output, this delay must expire before the output will turn on. The value in seconds, maximal limit is 3 hours (10800 seconds).	0

## Voice device (DECT Device)

### Advanced Configuration

Parameter	Description	Default Configuration
<b>Name</b>	Enter voice device name	
<b>Add Voice Device</b>	Use this Button to learn voice device into the system but not before pairing the DECT Voice device in Communication level.	Empty
<b>Is Active</b>	Panic event can be enable or disable from Voice device	Enable
<b>Emergency alarm</b>	Voce device generates Emergency Alarm instead Panic Alarm on pressing the panic button.	

### Area Assignment

Parameter	Description	Default Configuration
<b>Voice Device is assigned to areas</b>	Voice device can be assigned to Area 1-4 or multiple areas	Area 1

### Output Assignment

Parameter	Description	Default Configuration
<b>Voice device is assigned to outputs</b>	Voice device can be assigned to an output or multiple outputs	<b>Note:</b> This option is linked to selection of the commands <b>Can Toggle outputs</b> option in order to activate/deactivate an output

### Commands

Parameter	Description	Default Configuration
<b>Command disable</b>	Commands , ARM , STAY ARMED and Can Toggle outputs are disabled	
<b>Can ARM</b>	Voice device can ARM area or multiple areas that assigned to the voice device , area or multiple areas can be armed by pressing and holding the disconnect button of the voice device for at least 5 sec	
<b>Can Stay ARM</b>	Voice device can STAY ARM area or multiple areas that assigned to voice device , area or multiple areas can be armed by pressing and holding the disconnect button of the voice device for at least 5 sec	
<b>Can Toggle outputs</b>	Voice device can turn on/off an output that assigned to voice device , output or multiple outputs can be turn on ot off by pressing and holding the disconnect button of the voice device for at least 5 sec	

## Overview


### Walk Test

A Walk Test is a method for testing sensors without causing false system alarms. During a walk test, you will go through and intentionally activate sensors so that they are recognized by the system. The faulted zones will be displayed, but no alarms will be reported to the central station.


Read more: <https://www.alarmgrid.com/faq/what-is-a-walk-test>

Parameter	Description	Default Configuration
<b>Start Walk Test</b>	Walk test mode is usable in installer mode. By going through all the detectors registered in the system and activating them, the associated zone examined will be displayed on the page of the overview screen page and in order to allow verification that all zones are functioning properly.	-
<b>Start Maintenance Mode</b>	The purpose of this function is to prevent alerts, reports, sounding of sirens or keyboards in areas when performing installer maintenance work such as battery replacement.	-
<b>Stop Maintenance Mode</b>	Stop and exit from Maintenance Mode	-

Example of walk test screen



Walk test mode is usable in installer mode. By walking through all the detectors registered in the system and activating them, the associated examined zone will be displayed on the page of the overview screen page and in order to allow verification that

all zones are functioning properly by indicating a green check mark and a red dot. . By pressing on STOP walk test /End walk test button, terminates the walk test process. The results of the walk-test will be shown on the screen to verify which detectors were triggered during the walk-test mode.

**NOTE:** The device's indication LED light under test will flash green color during the walk test process.

An Output can be used for the Audible walk-test indication; the siren on the output will give a single tone for the chirp instead of the swept tone used for alarms.

In Addition, this page provides General Display information of Accessories (zone names, device serial #, state, device type, RSSI level , repeated zones, panel main communication (Ethernet, GSM/3G, WiFi ) status, radio frequency , panel versions (panel firmware, RF module, DECT ULE SW version).

## [Control](#)

Parameter	Description	Default Configuration
<b>ARM</b>	Key button for Area ARM	-
<b>DISARM</b>	Key button for Area DISARM	-
<b>STAY</b>	Key button for Area STAY ARM	-

## [Log](#)

Parameter	Description	Default Configuration
<b>Log</b>	Displays the logs events from C.P to cloud	
<b>Get internal log</b>	Displays the total logs events, from C.P. to cloud + C.P. internal events	-
<b>Update log</b>	Refresh the web page of the log events	-
<b>Log on page</b>	Ability to increase the number of display log events	1-30

## [...More](#)

Parameter	Description	Default Configuration
<b>Backup config/restore/save as Default</b>	Ability to create new backup and restore/save as default of the panel configuration	-
<b>Personal Page</b>	Option of displaying the personal page from installer programming mode	-
<b>Panel upgrade</b>	Uses to upgrade the panel firmware, RF module, DECT module from Cloud or Local file, this action is protected by inserting installer code, in addition there are options to create Backup and/or Restore prior the upgrade process	-
<b>Apply default</b>	Ability to upload default configuration file from a list which created in save as default action in backup Config by installer	-
<b>Reset Panel Connection</b>	Reset the connection socket from C.P. to cloud server	-
<b>Restart Panel</b>	Restart the panel doesn't affect the panel settings	-

## [Disconnect](#)

- Disconnect the remote connection from Panel

## CrowCloud™ Web Services

Your CUBE+™ panel is configured by default for direct communication to CrowCloud™.

After configuration of your panel, go to <http://www.Crowcloud.com> and proceed with the user registration to your CUBE+™ panel.



The Crow Cloud personal user webpage allows the end user direct access to all of its registered control panels.

This personal webpage offers to the end user possibility to:


- Connect to its registered control panel
- Monitor and Control panel and connected devices
- Browse alarm pictures and request for immediate take picture
- Get panel connection info
- Manage cloud users

**Login:** If you already have an account on Crow Cloud, fill these form

**Sign up:** Click this link to start registration of new user

**Forgot Password:** Click this link to retrieve your password

**Language:** Select your preferred language



**Email:**

Enter end user's email address.

**First Name:**

Enter the first name of the End User.

**Last Name:**

Enter the family name of the End User.

**Type password:**

Enter the password at least 8 alphanumeric characters

**Retype password:**

Confirm the password entered above

**Submit:**

Click this link to send form and create the user

Panels

Name	Version	MAC	Status
[REDACTED]	1.2.5.59	[REDACTED]	ONLINE
[REDACTED]	1.2.7.63	[REDACTED]	ONLINE
[REDACTED]	1.2.7.63	[REDACTED]	ONLINE

Add Panel to Account

Click on the desired control panel to access to its monitoring and control

**Welcome page of the CrowCloud™**

**Information on:**

- Name of registered control panels
- Firmware version
- MAC address of control panels
- Current Status of control panels

**From this page you can:**

- Edit list of registered control panels
- Add new control panel to user


Areas   ZONES   Outputs   Keypads   Users   Troubles   Pictures   Settings -


Areas


Area 1 Edit


Area 4 Edit

## Area 1

  
 ARM

  
 DISARM

  
 STAY

  
 PANIC

**Areas**

This part enables control of CUBE+™ panel

**Areas:**

Selection of the area to monitor/control

**ARM:**

Arming of the selected Area

**DISARM:**

Disarming of the selected Area

**STAY:**

Stay Arming of the selected Area

**PANIC:**

Press 5 sec to generate immediate Panic Alarm

Zones

ID	Name	Signal	Type	State	Areas	Status	Statistics	Temperature
1	Zone 1 <a href="#">Edit</a>		Camera PIR on CT2035	ready	Area 1			25 °C
3	Zone 3-FW2-Right <a href="#">Edit</a>		Magnetic contact	ready	Area 1			28 °C

**Note:** Only active zones will be listed

**Zones**

This part provides info/control on Zones

- Names of the active zones
- RSSI Signal of the zone
- Type of connected device
- State of the device
- Related area of the zone
- Status (Active/Bypass) of the zone
- Statistic (if device compatible) for Temperature, Air Quality, Humidity...

**Add Zones:** online learning of devices

Outputs

ID	Name	Signal	Type	State	Status	Statistics	Temperature
1	Output 1-IP CAM <a href="#">Edit</a>		AC Outlet with Simple Power Metering	ready			

**Outputs**

This part enable control on Outputs

- NAME:** Name of the outputs (ex: outdoor siren)
- TYPE:** Type of Output: Wired, Siren, Smart Plug...
- STATE:** Info on output trouble
- STATUS:** Activation / Deactivation of the output

Users

[Add user](#)

ID	Name	Action
1	User 1-Master	<a href="#">Edit</a>
2	User 2-A1	<a href="#">Edit</a>

**Users**

List of active users into the control panel.

- ID:** User position registered in control panel
- NAME:** Name of the user saved in control panel

Areas Zones Outputs Users Troubles Pictures Settings ▾

Troubles


Smoke DECT (zone 36): Tamper alarm

## Troubles

Information on current troubles detected

ID: 2239497 Created: 02-09-2019 - 15:02 [Delete](#)

(CAM WLED 15)



## Pictures

This part of the personal page gives to the end user information and control of connected PIRCAM detectors with the possibility to display pictures of all devices or select device from which you want to see saved pictures.

The End-User has also the possibility to Take Picture from selected PIRCAM detector.

Panel Info

Connected via Ethernet

Ethernet	Radio
Ip: 192.168.1.62	Software version: 0.41
Mac: 0013A120159D	Hardware version: 4.07
Mask: 255.255.252.0	Failure: false
Gateway: 192.168.0.240	Module id: 19816146
Id: ethernet	Freq: 868.85
	Id: radio

GSM	Wi-fi
Status: 0	Ssid: Crwlangu
No voice: false	Ip: 192.168.30.58
Roaming: false	Wifi rssi: -44
Ip: 10.49.3.242	Mask: 255.255.255.0
Id: gsm	Id: wifi
Mask: 255.255.255.255	Mac: 94E36D81693B
Status desc: OK	Dns: 8.8.8.8
Mobile rssi: -91	Rssi: -44
Band: 42501	Gateway: 192.168.30.240
Module hw: SARA-U201-04B-00	
Dns: 80.179.82.179	
Provider: Partner IL	
Imei: 358887096466287	
Rssi: -91	
Net: HSDPA	
Gateway: 10.49.3.242	

[Reset panel connection](#)

## Panel Info

This part provides info of current communication status:

Display of the current connection method

### Ethernet:

**IP:** internal IP of the panel in your network

**MAC:** Ethernet MAC of the CUBE+™

**Mask:** Network subnet mask

**Panel:** IP of the router

**ID:** Name of the communication method

### Radio:

Information on the Two Way wireless RF module for wireless ISM devices

### GSM:

Information received from cellular provider on the current GSM/GPRS/4G connection

### Wi-Fi:

Information on the Wi-Fi connection status inside your personal network

### Reset panel connection:

Restart panel communication methods

Notifications

Receive Push Notification	
Alarm	<input checked="" type="checkbox"/>
Troubles	<input checked="" type="checkbox"/>
Arm	<input checked="" type="checkbox"/>
Information	<input checked="" type="checkbox"/>
Take picture	<input checked="" type="checkbox"/>
Configuration	<input checked="" type="checkbox"/>
User association	<input checked="" type="checkbox"/>
All	<input checked="" type="checkbox"/>

Receive Pictures by Email	
Receive pictures	<input checked="" type="checkbox"/>

Notification language: English(US) ▾

Submit

**i** Notifications will be sent automatically to your account email address. You can set up other email addresses to get notified

[Add New email address](#)

**Details**

You can easily set up events notifications and select type of events sent to each emails addresses registered

**Information:** All type of information.

**Alarm:** Alarm occurs

**Troubles:** When the panel reports troubles

**Take picture:** In case of picture is requested

**User association:** When a new user is registered on the panel

**Configuration:** Enter in installer mode

**Arm:** When arming the system

You can also select which email is allowed to receive alarm pictures.

Areas   Zones   Outputs   Users   Troubles   Pictures   Settings ▾

Details

Panel name

Submit

## Details

This tab gives possibility to change control panel name in the cloud

## Mobile Applications



Friendly user guide will help you register and set up the Panel.  
Install the Crow Pro application on your smartphone (iOS / Android)

or open your web browser <http://www.CrowCloud.com>



All information and data contained in this document are proprietary and confidential. CROW Electronic Engineering Ltd. shall not be liable, in any event, for any claims for damages or any other remedy in any jurisdiction whatsoever, whether in an action in contract, tort (including negligence and strict liability) or any other theory of liability, whether in law or equity including, without limitation, claims for damages or any other remedy in whatever jurisdiction, and shall not assume responsibility for patent infringements or other rights to third parties, arising out of or in connection with this document.

Further, CROW Electronic Engineering Ltd. reserves the right to revise this publication and to make changes to its content, at any time, without obligation to notify any person or entity of such revision changes. These materials are copyrighted and any unauthorized use of these materials may violate copyright, trademark, and other laws. Therefore, no part of this publication may be reproduced, photocopied, stored on a retrieval system, or transmitted without the express written consent of CROW Electronic Engineering Ltd. Any new issue of this document invalidates previous issues.

**©CROW Electronic Engineering Ltd. 2018. All rights reserved.**

Information in this document is subject to change without notice.

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, without express written permission of CROW Electronic Engineering Ltd.

## Appendix 1: Installer Event log messages

AC Fail	Loss of AC power from the main panel
AC Restored	AC power restore on main panel
%O activated by %U	Output number %d activated by user number %U
%O activated by remote control	Output number %d activated remote control
*%Z Alarm in %A	Zone number %Z Alarm in Area number %A
Area Edited in %A by %S1	Area number %A label was Edited by Cloud user %S1
*%A Arm Failed	Area number %A arm operation failed
*%A Armed by Keypad %d	Area number %A armed via Keypad number %d
*%A Armed by Time Zone %d	Area number %A armed via Time zone number %d
*%A Arm Fail by Time Zone %d	Area number %A Arm fail by time zone number %d
Automatic Test Connect	Automatic communication test process finish successfully.
*%Z Bypass	Zone number %Z bypassed
*%Z Bypass Restore	Zone number %Z bypass restore
%U Bypass all Pendant Battery Low	User number %U is Bypassed all Pendants that at Battery Low status
Code Attempts Alarm	False code alarm
Code Attempts Restore	False code alarm restore
Communication (%Y) Fail	Communication method (IP/ GPRS/Wi-Fi) (%Y) Fail
Communication (%Y) Restore	Communication method restore on main panel
Control Panel Added to User %S1, By %S2	Control Panel Added to Cloud user %S1 By Cloud user %S2
Control Panel Deleted from User %S1, By %S2	Control Panel Cloud user %S1 deleted By Cloud user %S2
Control Panel User Edited for %S1, By %S2	Control Panel Cloud user %S1 edited By Cloud user %S2
%O deactivated by keypad %d	Output number %O deactivated by keypad number %d
%O deactivated by remote control	Output number %O deactivated by remote control
DECT Delete Headsets by %S1	DECT Headset device deleted by Cloud user %S1
DECT Pair Canceled by %S1	DECT device pair cancel by Cloud user %S1
DECT Pair Started by %S1	DECT device pair process started by Cloud user %S1
%A Delinquency Alarm	Delinquency alarm in Area number %A
%A Delinquency Restore	Delinquency report Area number %A Restore
*%A Disarmed by %U	Area number %A disarmed by User number %U
*%A Disarmed by Keypad %d	Area number %A disarmed by keypad number %d
*%A Disarmed by Keyswitch %d	Area number %A disarmed by Keyswitch number %d
*%A Disarmed by Time Zone %d	Area number %A disarmed by time zone number %d
%U Duress Alarm	Duress Alarm from User Number %U
Duress Alarm Reset	Duress Alarm restored
Enter Installer Mode	Entering installer programming from installer web interface or installer app.

Exit Installer Mode	Exiting installer programming from installer web interface or installer app.
*Fire Alarm from keypad %d	Fire Alarm from keypad number %d
*Fire Alarm Reset	Fire Alarm Restore
Full CFG View by %S1	Full configuration view by Cloud user %S1
*%Z 24 Hour Alarm	Zone number %Z 24 hour Alarm
*%Z 24 Hour Fire Alarm	Fire Alarm from Zone Number %Z
*%Z 24 Hour Fire Restore	24 Hour fire alarm restore zone number %Z
*%Z 24 Hour Restore	24 Hour alarm restore zone number %Z
*%Z Inactivity Alarm	Inactivity alarm from zone number %Z
*%Z Inactivity Restore	Zone number %Z inactivity alarm restore
Keypad %d Tamper	Keypad number %d tamper alarm
Low System Battery	Low battery fault from the main panel
*Medical Alarm from keypad %d	Medical alarm from KP number %d
*Medical Restore	Medical alarm restored
*%Z Near Alarm in %A	Zone number %Z near Alarm in Area number %A
*%Z Near Restore in %A	Near alarm restore zone number %Z in Area number %A
Output Deleted in %O by %S1	Output number %O deleted by Cloud user %S1
Output %d Fail	Output number %d operation failed
Output %d Tamper	Output number %d tamper alarm
*Panel Tamper	Panel Tamper alarm
Panel upgraded to new version	Panel upgraded successfully to new version
*Panic Alarm by pendant %U	Panic alarm by pendant User number %U
*Panic Alarm from keypad %d	Panic Alarm from keypad number %d
*Panic Alarm Reset	Panic Alarm Restore
*Pendant %U Battery Low	Low battery fault from pendant number %U
*Pendant %U Battery Restored	Pendant User %U Battery Restored
*Perimeter %Z Alarm in %A	Perimeter Alarm from Zone %Z in Area %A
*Perimeter %Z Restore in %A	Perimeter Alarm restore from Zone %Z in Area %A
Peripheral Battery Low	Battery Low was occurred in mail panel peripheral device
*Radio %O Battery Low	Low battery fault from output number %O
*Radio %O Battery Restored	Output number %O Battery Restored
*Radio %Z Battery Low	Low battery fault from Zone number %Z
*Radio %Z Battery Restored	Low battery restore fault from Zone number %Z
*%A Remote Disarm	Area number %A remote disarmed
*%A Remote Stay Arm	Area number %A remote stay armed
Report Channel %d failed	Report Channel number %d communication failed
%Z Restore in %A	Burglary alarm restore zone number %Z in Area number %A
RF module upgraded	RF module upgraded successfully
%A Stay Armed by Keypad %d	Area number %A stay armed by keypad number %d
%A Stay Disarmed by %U	Area number %A stay disarmed by User number %U
%A Stay Disarmed by Time Zone %d	Area number %A stay disarmed by time zone number %d
Supervised Radio %Z Restore	Supervision restore event from zone number %Z
System Battery Dead	Empty battery of the main panel
System Peripheral Trouble	Trouble was occurred in mail panel peripheral device
System restarted	The control panel has reset

Take Picture in %Z Started by %S1	Take picture from PIRCAM Zone %Z started by Cloud user %S1
Take Picture in %Z Success	Take picture from PIRCAM Zone %Z Succeed
%Z Tamper	Tamper alarm from zone number %Z
%Z Verified Alarm in %A	Verified Alarm from Zone %Z in Area %A
Upgrade Failed by %S1	Panel upgrade failed by Cloud user %S1
Upgrade Started by %S1	Panel upgrade started by Cloud user %S1
User Deleted in %U by %S1	User number %U deleted by Cloud user %S1
Walk Test Started by %S1	Walk test started by Cloud user %S1
Zone Edited in %Z by %S1	Zone number %Z label was Edited by Cloud user %S1
Zone Params Edited in %Z by %S1	Zone number %Z parameters were Edited by Cloud user %S1
Zone %Z to Output %O Edited by %S1	Assign Zone %Z to Output %O was done by Cloud user %S1

\* Event log display cannot be suppressed, as specified by EN50131-1-2006

### **Compliance Standards**

- EN 301489-1
- EN 301489-3
- EN 301489-52
- EN 301 489-17
- EN 301 489-6
- EN 300 328
- EN 61000-6-3
- EN 50130-4
- EN 300220-1
- EN 300220-2
- EN 62368-1
- EN 50130-5
- EN 50131-1
- EN 50131-3
- EN 50131-6
- EN 50131-10
- EN 50136-1
- EN 50136-2
- EN 50131-5-3

Certification body: Kiwa Nederland B.V.  
Security Grade 2, Environmental Class II  
PS type A

### **Pass-through operation feature:**

The control panel working with pass-through mechanism.

The SPT shall not acknowledge the alarm to the AS before receiving an acknowledgement from the RCT. When the SPT receives an acknowledgement from the RCT, the acknowledgement shall be forwarded to the AS.

### **REDUNDANCY / DUPLICATION:**

All events are transmitted and received via TCP/IP interface (primary). In case of primary channel fail, the event will be transmitted via the secondary back-up channel (GPRS).

**ATS UNAVAILABILITY:**

The ATS sends all faults to ARC(s) in any case except case then the ATS unavailable due to maintenance by accredited person with appropriate access level

**ARC - alarm receiving centre**

**AS - alarm system**

**ACE – ancillary control equipment**

**AE – annunciation equipment**

**ATP – alarm transmission path**

**ATS - alarm transmission system**

**CIE - control and indicating equipment**

**HAS - hold-up alarm system(s)**

**IAS - intruder alarm system(s)**

**I&HAS – intrusion and hold-up alarm system(s)**

**WD – warning device**

**PS- power supply**

**RCT – receiving center transceiver**

**SPT - supervised premises transceiver**

❖ Remote access capabilities of CR-CP-FB:

1. **Remote Access Functionality:**

The system supports remote access for the following purposes:

- System configuration
- Status monitoring
- Remote maintenance
- Event log retrieval

2. **Security Measures Implemented:**

To ensure the integrity and security of remote access, the following measures are implemented:

- Authentication by password
- Encrypted communication channels – TLS 1.2
- Access logging and traceability
- Access level control (user-based permissions)

3. **Compliance Statement:**

The remote access functionality is implemented in a way that does not compromise the system's compliance with the relevant requirements of EN 50131-1. It is ensured that:

- The system maintains its intended performance level (Grade)
- Any remote intervention is traceable
- Unauthorized access is prevented

4. **Access Management:**

- Only authorized personnel and the owner of the I&HAS have access to the system remotely
- Remote user access is disabled, until the unique identification and validation is confirmed, if the remote access user interface is not being use (automatic logout if no activity)
- Access credentials are managed securely

❖ Substitution Security is accomplished by Information Security, by physical security and by designating a unique Serial Number for each component.

- Each CR-CP-FB has a special housing design and two tamperers (top and bottom magnet switches), that protect against physical penetration and substitution of the system elements (modules and configuration).
- Each CR-CP-FB has unique serial number, MAC-address and IMEI, which allows to identify the security system.
- In all communications by TCP/IP used unique account number of ATS in events and encryption by TLS 1.2 encryption key.

❖ In accordance with the requirements set out in EN 50136-1:2012+A1:2018 and EN 50136-2:2013+A1:2023:

The ATS category of the system is classified as DP3, and it utilizes the following alarm transmission paths:

- Primary path: IP (Ethernet/Wi-Fi)
- Secondary path: GSM

The system complies with the performance requirements defined in EN 50136-1, including:

- Arithmetic mean of all transmissions: 20 seconds
- 95% of all transmissions: 30 seconds
- Maximum acceptable transmission time: 60 seconds
- Maximum Primary Path Reporting Time: 3 minutes
- Maximum Secondary Path Reporting Time (when Primary operational): 25 hours
- Maximum Secondary Path Reporting Time (when Primary failed): 3 minutes
- Maximum All Paths Failure (at the same time) Reporting Time: 4 minutes

- ❖ Technical descriptions and compliance statements regarding the Alarm Transmission System (ATS) functionality integrated within wireless control panel CR-CP-FB. The control panel includes an onboard Supervised Premises Transceiver (SPT) and is certified in accordance with EN 50131-1.

The information below is provided in response to compliance verification requirements under EN 50136-1 and EN 50136-2.

1. Supported receiving center transceiver(s) (RCT) types and/or protocols:

The onboard SPT is compatible with RCTs supporting SIA DC-09 protocols over TCP/IP protocol. Compatibility has been verified with generic SIA-compatible receivers

2. Method of operation by which the SPT signals alarm transmission path (ATP) failures to the alarm system (AS):

The SPT continuously monitors the IP connection for report channels 1-7 SIA DC-09 via heartbeat polling null event every 20 seconds and monitor mediator via Crow protocol every 1 minute. If no ACK is received, the SPT triggers a fault signal to the control panel, indicating ATP failure immediately. The alarm panel logs the fault and can forward it to users or the ARC.

3. Monitoring of the transmission network interface:

The Ethernet and Wi-Fi interface are monitored for link status using standard OSI layer 2 checks. If the interface is unplugged or link drops, a failure is logged. For GSM, the module continuously monitors signal level, SIM presence, and registration with the mobile network. Any critical fault results in a local fault indication and can be reported to the alarm panel.

4. Operation mode:

The SPT supports store-and-forward operation. In case of communication failure, the message is stored in non-volatile memory until it will be delivered (ACK of delivery shall be received), Pass-through is used during normal operation when the transmission path is available.

5. Redundancy / Duplication methods:

The onboard SPT provides dual-path communication using primary IP (Ethernet + Wi-Fi) and secondary GSM/LTE. At least one ATP exists between the alarm panel (AS) and the ARC. Signals are normally transmitted via the IP path, and in the event of failure (e.g., loss of link or no acknowledgment), the system automatically switches to Wi-Fi and to GSM (if required) to maintain continuity of service.

6. Detection of ATS unavailability:

The SPT continuously monitors all transmission paths:

Ethernet and Wi-Fi and GSM/LTE monitored via polling/heartbeat (every 20 sec). Failure is detected if no ACK is received. The fault message generated immediately if no ACK received.